SEICOS-pcFLexi

INSTRUCTION MANUAL

OPERATION

60 Edition 1.01

NO-0000-1-0300-E-1-01



Hitachi Seiki Deutschland Werkzeugmaschinen GmbH

CONTENTS

I.	C	OUTLINE	1 - 1
II.	S	PECIFICATIONS	2 - 1
1.	С	ONTROLLED AXES	
	1-1	Controlled Axes	
	1-2	Simultaneous Controllable Axes	
	1-3	Setting Unit	
	1-4	Maximum Commandable Value	
	1-5	Position Detector	
2.	IN	ITERPOLATING FUNCTIONS	
	2-1	Positioning (G00)	
	2-2	Linear Interpolation (G01)	
	2-3	ANGLE DESIGNATION LINEAR INTERPORATION (G01)	
	2-4	Circular Interpolation (G02, G03)	
	2-5	Radius Designation on Arc (G02, G03)	
	2-6	Helical Cutting	
	2-7	Polar Coordinate Interpolation	
	2-8	Cylindrical Interpolation	
3.	Т	HREADING	
	3-1	THREADING (G32)	
	3-2	MULTIPLE THREADIGN (G32)	
	3-3	VARIABLE LEAD THREADING	
4.	F	EED FUNCTION	
	4-1	RAPID TRAVERSE RATE AND RAPID OVERRIDE	
	4-2	CUTTING FEED RATE AND FEED OVERRIDE	
	4-3	Override Cancel	
	4-4	Automatic Acceleration/Deceleration	
	4-5	Dwell (G04)	
	4-6	Exact Stop Check (G09)	
	4-7	Exact Stop Check Mode (G61)/Cutting Mode (G64)	
5.	R	EFERENCE POINT	
	5-1	Reference Point Return (G28)	
	5-2	Second reference Point Return (G30)	
	5-3	Third/Fourth Reference Point Return (G30)	
6.	С	OORDINATE SYSTEM	
	6-1	Tool Nose Coordinate System	
	6-2	Coordinate System Setting (G50)	
	6-3	Machine Coordinate System Selection (G53)	
	6-4	Plane Designation (G17, G18, G19)	
7.	С	OORDINATES AND DIMENSIONS	2 - 5

7-1	Absolute/Incremental Programming	2 - 5
7-2	Decimal Point Input	2 - 5
7-3	Inch/Metric Conversion (G20, G21)	2 - 5
8. 5	PINDLE FUNCTIONS	2 - 5
8-1	Spindle Function	2 - 5
8-2	Spindle Override	2 - 5
8-3	Constant Surface Speed Control (G96, G97)	2 - 5
9. T	OOL FUNCTIONS	2 - 6
9-1	Tool Function	2 - 6
10. N	/ISCELLANEOUS FUNCTIONS	2 - 6
10-1	Miscellaneous Function	2 - 6
11. F	PROGRAM CONSTRUCTION	2 - 7
11- 1	Command Tape	. 2 - 7
11-2	2 Tape Format	2 - 7
11-3	3 Input Format	2 - 7
11-4	Command Tape Codes	. 2 - 7
11-5	5 Command Words and Command Value Ranges	. 2 - 8
11-6	Subprogram (M98, M99)	2 - 8
11-7	Programmable Mirror Image (G501, G511)	2 - 8
11-8	3 Optional Block Skip	. 2 - 8
11-9	O Control-in/-out	. 2 - 8
11-1	0 Command Data Input Methods	2 - 9
11-1	1 Internal Data Output Methods	. 2 - 9
12. H	IOW TO FACILITATE PROGRAMMING	2 - 9
12-1	Canned Cycle for Drilling (G80~G87, G89, G831, G841, G861)	2 - 9
12-2	2 Fixed Cycle (G90, G92, G94)	2 - 9
12-3	3 Maltipul Fixed Cycle	2 - 9
13. T	OOL OFFSET FUNCTIONS	2 - 10
13-1	Automatic Tip R Compensation and Cutter Compensation	2 - 10
13-2	2 Groove Width Compensation (G150 to G152) 2	2 - 10
13-3	3 Addition of Tool Offsets	2 - 10
14. <i>A</i>	CCURACY COMPENSATING FUNCTIONS	2 - 10
14-1	Backlash Compensation2	2 - 10
14-2	2 Stored Pitch Error Compensation	2 - 10
15. N	IEASURING FUNCTIONS	2 - 11
15-1	Skip Function	2 - 11
15-2	2 Q SETTER	2 - 11
15-3	3 Q-setter Repeat Function	2 - 11
16. C	CUSTOM MACRO	2 - 11
16-1	Custom Macro	2 - 11
17. A	XIS CONTROL	2 - 11
17-1	Follow-up Function	2 - 11
18. N	IANUAL OPERATION	2 - 12
18-1	Manual Continuous Feed	2 - 12

18-2	Manual Pulse Generator	. 2 - 12
19. A	UTOMATIC OPERATION	. 2 - 12
19-1	Program Number Search	. 2 - 12
19-2	Sequence Number Search	. 2 - 12
19-3	Feedhold	. 2 - 12
20. P	ROGRAM TEST FUNCTIONS	. 2 - 13
20-1	Machine Lock	. 2 - 13
20-2	Dry Run	. 2 - 13
20-3	Single Block	. 2 - 13
21. D	ISPLAY AND SETTING	. 2 - 13
21-1	Machining End Notice	. 2 - 13
21-2	Run Hour Display	. 2 - 13
21-3	Work Count Function	. 2 - 13
22. P/	ART PROGRAM STORAGE & EDITING	. 2 - 14
22-1	Part Program Storage & Editing	. 2 - 14
22-2	Part Program Comparison	. 2 - 14
23. D	IAGNOSTIC FUNCTIONS	. 2 - 14
23-1	Self Diagnostic Function	. 2 - 14
23-2	Alarm Diagnosis	. 2 - 14
24. D	ATA INPUT AND OUTPUT	. 2 - 14
24-1	Input/Output Interface (RS-232C)	. 2 - 14
25. S	AFETY FUNCTIONS	. 2 - 15
25-1	Emergency Stop	. 2 - 15
25-2	Overtravel	. 2 - 15
25-3	Interlock	. 2 - 15
25-4	Stored Stroke Limit 1	. 2 - 15
25-5	Stored Stroke Limit 2 and 3 (G22, G23)	. 2 - 15
25-6	Stroke Check Before Move	. 2 - 15
III. C	PERATION	3 - 1
	asia Machina Operation	~ ~
1 M		
1. IVI 1.1		
1-1 1-2	Manual Potoronco Point Poturn	3 - 3
1-2		3 - 4 2 1
1-3 1_4	Manual Handle Food	3-5
1- 4 Ο Δ		3 - 5
2. A		
2-1	Selecting the Pup Program	3 - 0 2 - 6
2-2	Stepping the Automatic Operation	3 - 0
∠-3 2 4		، - د ح د
2-4 2 E		ა-/ იი
2-0	Ongre Diock	0-0. 2.0
2-0	Overhide	0-5
з. U	peration related to Salety	3 - 9

	3-1	Emergency stop	3	5 - 9
	3-2	Overtravel	3	; - 9
4.	N	C Operation keys	3 -	10
5.	5. Quick Tool Setter (Q Setter)		3 -	12
	5-1	Outline	3 -	· 12
	5-2	Operation Method	3 -	· 12
	5-3	Tool Nose Point Interlock	3 -	· 15
	5-4	Related Parameters	3 -	· 15
	5-5	Related Alarms	3 -	· 16
6.	Q	setter barrier	3 -	17
	6-1	Outline	3 -	· 17
	6-2	Description of the function	3 -	· 17
	6-3	Precautions	3 -	· 18
	6-4	Related parameters	3 -	· 18
7.	Q	Setter Repeat Function	3 -	19
	7-1	Outline	3 -	· 19
	7-2	Operation	3 -	· 19
	7-3	Working	3 -	· 20
	7-4	Precaution	3 -	· 23
	7-5	Relevant Parameters	3 -	· 23
	7-6	Relevant Alarms	3 -	· 24
8.	Si	mple Jaw Edge Forming Function	3 -	25
	8-1	Outline	3 -	· 25
	8-2	Operation	3 -	· 25
	8-3	Function Keys	3 -	· 26
	8-4	Jaw Configuration And Machining Conditions	3 -	· 27
	8-5	Precaution	3 -	- 27
	8-6	Relevant Parameters	3 -	- 28
	8-7	Relevant Alarms	3 -	- 28
	8-8	Set Values for Standard Soft Jaws	3 -	- 29
	8-9	Operation Of Simple Soft Jaw Forming Function	3 -	- 31
111.	II Sc	preen Operation	3 -	37
1.	Sc	reen Layout and Basic Operation	3 -	38
	1-1	Main Display Area	3 -	. 39
	1-2	Machine Status Display Area	3 -	- 39
	1-3	Program Number Display Area	3.	- 40
	1-4	Kev Input Area	3.	- 40
	1-5	Function Menu	3.	- 40
	1-6	Tree Chart	3.	- 41
2	Or	peration of Overall Screen	3-	45
	2-1	Program Window	3.	- 46
	2-2	Drawing Window	3.	- 46
	2-3	Tool Window	3.	- 46
	2-4	Position Window	3.	- 47
	-			

	2-5	Wear Compensation	3 ·	- 47
	2-6	Macro Variables	3 ·	- 48
	2-7	Running Status	3 ·	- 48
	2-8	Axis Load Display	3 ·	- 49
	2-9	Command Value	3 ·	- 49
	2-10	Program List	3 -	- 49
	2-11	G Code M Code	3 ·	- 50
	2-12	Diagnose	3 ·	- 51
	2-13	Return to Standard Screen	3 ·	- 51
	2-14	Spare Tool (Option)	3 ·	- 51
3.	Po	sition	3.	- 52
	3-1	Reloading of Relative Coordinate System	3 ·	- 52
	3-2	Command Value Display	3 ·	- 53
	3-3	Set up	3 ·	- 54
4.	W	ork Coordinates (Offset)	3.	- 55
	4-1	Removal Amount	3 ·	- 56
	4-2	Machining Reference Point Shift	3.	- 56
	4-3	Work Length	3 ·	- 56
	4-4	Setting of 2nd Reference Point	3.	- 57
5.	Se	et (Data)	3.	- 58
	5-1	PROGRAM	3 ·	- 58
	5-2	CANNED CYCLE	3.	- 58
	5-3	STROKE	3 ·	- 59
	5-4	ECO eco	3.	- 60
	5-5	Chuck Setting(Option)	3 ·	- 61
	5-6	Tail Stock Setting(Option)	3.	- 62
6.	Ма	acro Variable	3.	- 64
	6-1	Macro Variable and Data Display	3.	- 64
	6-2	Number Search	3.	- 65
7.	Plo	ot	3.	- 66
8.	Pr	e-machining Plotting	3.	- 67
9.	Plo	otting Parameters	3.	- 68
10). То	ol (offset)	3.	- 72
	10-1	Setting of Offset Value	3.	- 73
	10-2	Tool Selection	3.	- 73
	10-3	Data Clear	3.	- 75
	10-4	Number Search	3.	- 75
11	. Ala	arm Diagnosis	3.	- 76
	11-1	Alarm History	3	- 77
12	2. Sv	vstem	3.	- 78
	12-1	Parameter	3	- 79
	12-2	Assembly Adjustment	3.	- 80
	12-3	ParaShot2000	3	- 81
	12-4	Software Version	3	- 82
	-		-	

12-5	Date and Time	3 - 83
12-6	LAN/UUP	
12-7	LANGUAGE	3 - 85
12-8	LSSOL Infomation	3 - 86
12-9	STAF Setting	3 - 87
12-10)Y MENU	
13. Pr	ogram	
13-1	Operating Key Input Area On Screen	3 - 90
13-2	Displaying Program	
13-3	Creating New Program	
13-4	Deleting Program	3 - 91
13-5	PROGRAM SEARCH	
13-6	Program Copy	3 - 91
13-7	Changing Program Number	
13-8	Program Editing (Edit Mode or Background Editing)	3 - 92
13-9	Word Search	3 - 93
13-10	Background Edit (Program Screen Only)	
13-11	Range Assignment Edit Operation (Program Screen Only)	
13-12	2Word Convert (Program Screen Only)	
13-13	3Macro Variables	3 - 99
14. Pr	ogram List	3 - 100
14-1	Program List	3 - 100
14-2	Program Search	3 - 102
14-3	Program Deletion	3 - 102
14-4	Program Merging	3 - 103
14-5	Directory Setting	3 - 104
15. Inj	put / Output	3 - 107
15-1	Program List	3 - 110
15-2	Setting Data	3 - 110
16. Te	st Operation	3 - 112
17. Ma	anual Operation	3 - 113
18. Us	ser Screen	3 - 114
18-1	How to oprate User Screen	3 - 115
18-2	Setting Screen	3 - 116
18-3	Input/Output	3 - 118
19. Q	Setter Setting	3 - 120
20. La	dder Live Line Display	3 - 121
20-1	Ladder Live Line Display Screen	3 - 121
20-2	Search	3 - 126
20-3	Cross Reference	3 - 127
20-4	Return to pcFLexi screen	3 - 130

I. OUTLINE

SEICOS-pcFLexi are products that have integrated the latest device technology and realized down-sizing with high reliability.

The machine is designed by giving consideration to users standpoint in the operating system as the man-machine interface, thus offers a most easy-to-operate machine.

As for the subject of programming, refer to "SEIKI-SEICOS pcFLexi program part" and for subjects on alarms and maintenance to "SEIKI-SEICOS pcFLexi maintenance part" respectively.

1. Items requiring attention when reading this manual.

- (1) In this manual and the reference manual "program part", explanations are made on all the functions that are applicable to these NC machines, including optional functions. The option function selected for adoption are different for each machine. Please confirm the specification of the machine beforehand, as there may be some functions referred to in the manual are not usable depending on the machine.
- (2) In this manual, those functions not specifically remarked "able" should be understood as "unable".
- (3) The contents of this manual may be changed without notice to meet a future machine improvement.
- Note) Programs, parameters, macro variables and tool compensation amounts, etc. are stored in the memory of NC unit. Generally, these data are not lost by switching the power ON/ OFF.

Nevertheless, data could be lost inadvertently or by erroneous operation. Also a case may occur when you are compelled to have valuable date in the memory cleared for restoring the system from a trouble.

To cope with such an unexpected situation, we suggest that you take note of the important data and keep them separately. It facilitates quick restoration of working condition of the machine by re-entering the data.

Note) When processing a work, do not start the operation suddenly. Make a trial warm-up run first for fully confirming that the machine acts correctly, then proceed with subsequent operating procedures.

II. SPECIFICATIONS

1. CONTROLLED AXES

1-1 Controlled Axes

The 3 axes, X, Z and spindle are controllable. Optionally, additional axes can be added. 13 axes are controllable in total.

1-2 Simultaneous Controllable Axes

The 2 axes, X and Z, can be controlled simultaneously regardless of rapid traverse or cutting feed. Table 1-2 shows the configuration of the controlled axes.

	No. of Axes	Axis Name	Remarks
Standard controlled axes	3 axes	X, Z, Spindle	
Additional axes control	10 axes	Select out of Y, A, B and C	Including other controllable
Simultaneous controllable axes	Standard 2 axes + additional axes	All the axes specified by the system	

Table 1-2

Note 1) The number of controlled axes, and relations between the axis name and axes can be selected with parameters.

1-3 Setting Unit

It is determined by parameters of computing resolution. The display resolution is determined by other parameters. Switching between millimeter/inch is set by G codes.

1-4 Maximum Commandable Value

Table 1-3

mm (G21)	±9999999.999 (mm, deg)
inch(G21)	±399999.999 (inch, deg)

1-5 Position Detector

The absolute encoder is provided as a standard position detector. Optionally, the pulse scale or the Inductosyn detecting function can be selected. When the Inductosyn detecting function is selected, however, you need a converter which serves as an interface equivalent to the pulse scale.

2. INTERPOLATING FUNCTIONS

2-1 Positioning (G00)

Can be fed at a rapid traverse rate independently by specifying G00.

2-2 Linear Interpolation (G01)

Linear interpolation is performed at the feed rate specified by an F-code in a G01 command.

2-3 ANGLE DESIGNATION LINEAR INTERPORATION (G01)

With G01, an angle from Z axis is specified where linear interpolation is commanded.

2-4 Circular Interpolation (G02, G03)

Circular interpolation can be performed arbitrarily at 0° to 360° at the feed rate specified by an F-code in a G02 or G03 command.

2-5 Radius Designation on Arc (G02, G03)

R can be directly specified as a circular arc radius value, assuming, I, J, and K to be a vector amount from a start point to the center in circular interpolation.

2-6 Helical Cutting

Another axis is linearly interpolated synchronously with circular interpolation.

2-7 Polar Coordinate Interpolation

A command programmed in the orthogonal coordinate system is converted into a linear axis move (tool) and rotary axis move (work rotation) to control a profile.

2-8 Cylindrical Interpolation

If a linear axis stroke and rotary axis angle are specified by a program command, the rotary axis stroke internally specified in terms of angle is converted into a distance on the circumference. As the distance on the circumference can be regarded a linear axis stroke on the circumference, linear interpolation and circular interpolation can be performed in combination with other linear axis.

3. THREADING

3-1 THREADING (G32)

With F code, a thread lead is directly commanded.

3-2 MULTIPLE THREADIGN (G32)

Use this to perform multiple thread cutting which has two or more thread ridges in a lead. With Address Q, command a threading start shift angle. be performed.

3-3 VARIABLE LEAD THREADING

By commanding the increase or decrease amount in lead per one screw thread turning, you can perform variable lead threading. With Address K, command a lead changing amount.

4. FEED FUNCTION

4-1 RAPID TRAVERSE RATE AND RAPID OVERRIDE

The maximum speed available in the axial direction is 999,999.999mm/min. Further, override can be applied to rapid traverse by rapid override.

4-2 CUTTING FEED RATE AND FEED OVERRIDE

The maximum feed rate range available for setting is 0.001~999,999.999mm/min. Override can be applied, by feed rate override, within a range of 0~200%.

4-3 Override Cancel

A cutting feed override rate can be fixed at 100 % by a signal from the machine.

4-4 Automatic Acceleration/Deceleration

When starting or stopping the axis travelling, it is automatically accelerated or decelerated.

4-5 Dwell (G04)

Migration to operation in the next program block can be delayed by a specified time by a G04 command. Use P, X, or U for an address.

4-6 Exact Stop Check (G09)

In the block where G09 is specified, an imposition check is made at the end of block execution.

4-7 Exact Stop Check Mode (G61)/Cutting Mode (G64)

Normally, the G64 mode is effected and the program proceeds to the next block immediately after interpolation is completed. If G61 is specified, the program will proceed to the next block after entering imposition at the end point of each block, in the subsequent move command. The G61 mode is cancelled by specifying G64.

5. **REFERENCE POINT**

5-1 Reference Point Return (G28)

Reference point return includes the following:

- (1) Manual reference point return.
- (2) Automatic reference point return (G28)

5-2 Second reference Point Return (G30)

Second reference point return (G30) returns the axes to the position set in a parameter.

5-3 Third/Fourth Reference Point Return (G30)

The axes can be returned to the 3rd/4th reference point preset by a G30 command (P3, P4).

6. COORDINATE SYSTEM

6-1 Tool Nose Coordinate System

At the time of turret indexing or manual zero point return, the tool nose position assuming the machining reference point to be zero (0) is automatically set in the coordinate system.

6-2 Coordinate System Setting (G50)

An axis command following G50 sets the coordinate system where a current tool coordinate value will be a specified value.

6-3 Machine Coordinate System Selection (G53)

A tool moves to a position in the machine coordinate system by a G53 command.

6-4 Plane Designation (G17, G18, G19)

A G-code is used to specify the plane where you want to perform circular interpolation,

tool diameter compensation, and so on.

G17: X-Y plane, G18: Z-X plane, G19: Y-Z plane

7. COORDINATES AND DIMENSIONS

7-1 Absolute/Incremental Programming

Absolute/incremental programming is switched by a G-code.

Absolute : X Y Z Incremental : U V W

7-2 Decimal Point Input

A decimal point can be input to the command data associated with a distance (angle), speed, and dwell. A decimal point position is after the millimetric or inch units digit. The addresses which can use decimal points are X, Y, Z, A, B, C, D, H, U, V, W, I, J, K, R, P, Q, E, and F.

Depending on conditions applies, however, a decimal point may not be usable.

7-3 Inch/Metric Conversion (G20, G21)

You can select the inch system/metric system as units of input by specifying G20/G21.

- G20: Inch input
- G21: Metric input

8. SPINDLE FUNCTIONS

8-1 Spindle Function

The rotating rate is specified by a numerical command following the address S.

8-2 Spindle Override

The override is applied by an external signal.

8-3 Constant Surface Speed Control (G96, G97)

With a surface speed directly assigned with S code, this function serves to continuously control the spindle motor rpm so that the circumferential speed is held constant to changes in tool position. Command to make this function valid or invalid is performed with G code.

- G96: Constant surface speed control is performed.
- G97: Constant surface speed control is not performed.

9. TOOL FUNCTIONS

9-1 Tool Function

Code signal is sent out by specifying an address T followed numerical command. Use T code, tool rest indexing, setting of a work coordinate system (tip coordinate system), combined compensation, etc..

10. MISCELLANEOUS FUNCTIONS

10-1 Miscellaneous Function

The machine can be turned on/off by specifying an address M followed numerical value.

11. PROGRAM CONSTRUCTION

11-1 Command Tape

8-unit black paper tape

11-2 Tape Format

EIA/ISO (At input: Automatic recognition, At output: Selected by a parameter)

11-3 Input Format

A variable-block, word-address format with decimal point is used.

11-4 Command Tape Codes

Address	Description
А	Additional axis coordinate value
В	Additional axis coordinate value
С	Additional axis coordinate value
F	Feed functions
G	Preparatory functions
Н	Incremental coordinate value C axis
Ι	X-axis component of the circular arc center
J	Y-axis component of the circular arc center
K	Z-axis component of the circular arc center
L	Canned cycle times designation, Repeat times in a subprogram call
М	Miscellaneous function
Ν	Sequence number
0	Program number
Р	Dwell, Program number in a subprogram call
Q	Fixed cycle
R	Radius command value for circular interpolation, Canned cycle
S	Spindle functions
Т	Tool functions
U	Incremental coordinate value X axis, Dwell
V	Incremental coordinate value Y axis
W	Incremental coordinate value Z axis
Х	X-axis coordinate value, Dwell
Y	Y-axis coordinate value
Z	Z-axis coordinate value

Table 11-4

11-5 Command Words and Command Value Ranges

Function	Address	Metric input.	Inch Input.
Program number #	0	0001~9999	0001~9999
Sequence number #	Ν	1~99999999	1~99999999
Preparatory function	G	0~999	0~999
Coordinate value	X, Y, Z,		
	U, V, W,	±999999.999(mm)	±39999.999(inch)
	I, J, K,		
	Q, R,	±999999.999(deg)	±999999.999(deg)
	A, B, C,		
Feed function	F		
Spindle function	S	0.001~999999.999	0.001~999999.999
Tool function	Т		
Miscellaneous functio	n M	0~2147483647	0~2147483647
Dwell	P, X, U	0~999999.999(sec)	0~999999.999(sec)
Call program number	Р	0001~9999	0001~9999
Repeat times	L	1~9999	1~9999

Table 11-5

11-6 Subprogram (M98, M99)

A subprogram can be called in the MEMORY mode. A called subprogram can further call another subprogram.

11-7 Programmable Mirror Image (G501, G511)

A mirror image can be applied to each axis by a program command.

11-8 Optional Block Skip

A program block containing a slash code, "/", in its beginning is ignored by turning on the OPTIONAL BLOCK SKIP switch provided on the part of the machine. This is valid only 1 pce. at the top of the block. You can add "/2" through "/5" as an option.

11-9 Control-in/-out

"(": Control-out

")": Control-in

This function is used when giving a program name to a program number or giving a comment halfway a program. All the information between control-out and control-in is ignored within a significant information section.

11-10 Command Data Input Methods

- (1) MDI (manual data input) through the keyboard
- (2) Inputting from an external input/output device via an RS-232C interface (Reading the NC tape)

11-11 Internal Data Output Methods

- (1) Displaying on the CRT
- (2) Outputting to an external input/output device via an RS-232C interface (Punching out the NC tape)

12. HOW TO FACILITATE PROGRAMMING

12-1 Canned Cycle for Drilling (G80~G87, G89, G831, G841, G861)

Drilling, tapping, and boring cycles can be specified in one program block.

12-2 Fixed Cycle (G90, G92, G94)

The following 3 kinds of fixed cycles can be commanded:

- (1) Cutting cycle A (G90) \rightarrow outside/inside diameter cutting
- ② Threading cycle (G92)
- (3) Cutting cycle B (G94) \rightarrow end face cutting

12-3 Maltipul Fixed Cycle

Several kinds of fixed cycles are prepared beforehand to facilitate a program. With information of the finished configuration alone being given, the tool passage for rough cutting to the end is automatically fixed. A fixed cycle for threading is also available.

13. TOOL OFFSET FUNCTIONS

13-1 Automatic Tip R Compensation and Cutter Compensation

 (1) Automatic Nose R Compensation (G143)
It is normally held at G143 (Automatic Nose R Compensation Valid Mode). Therefore, without G code not being commanded, tip R compensation is automatically executed.

Nose R is set to tool compensation R and virtual nose points (1~8) to T.

(2) Cutter Nose R Compensation (G145 : G40~G42)

G145 command turns it to the Tool Diameter/Nose R Offset Valid Mode. If the tool type is a rotary tool, it turns to the tool diameter offset, if a cutting tool, it turns to the nose R offset.

During this mode, using G40~G42 commands, you can perform the Tool Diameter/ Nose R Offset. Set the tool diameter/nose R to the R of the tool offset and the virtual nose point (9) to the T.

13-2 Groove Width Compensation (G150 to G152)

When a grooving tool is used, one virtual tool nose (for example, 3) is used to run the program to apply compensation. It is also necessary to compensate the other virtual tool nose (for example, 4) side. When this is done, this function compensates the groove width by specifying a G-code.

13-3 Addition of Tool Offsets

The number of tool offset pairs can be expanded up to 200. Expansion of tool offset pairs: 64/99/200

14. ACCURACY COMPENSATING FUNCTIONS

14-1 Backlash Compensation

This function is to compensate the lost motions which the mechanical system has. A compensation amount can be set as a parameter in the least command increment for each axis.

14-2 Stored Pitch Error Compensation

This function is to compensate a pitch error for feed screws. Compensation data is set as a parameter.

15. MEASURING FUNCTIONS

15-1 Skip Function

If a skip signal is input from an external device in the midst of an X-, Y-, or Z-command following G31, the next block will be executed, canceling the rest of this command. A skip signal input position can be read with a system macro variable.

15-2 Q SETTER

Through simple manual operation with the touch sensor, tool offset volume is automatically written.

15-3 Q-setter Repeat Function

By measuring the tool with the Q-setter once, automatic measurement with the Q-setter is activated by simple operation when changing tips.

16. CUSTOM MACRO

16-1 Custom Macro

A function peculiar to the user can be created. There are 100 common variables, but their number can be optionally extended up to 600.

17. AXIS CONTROL

17-1 Follow-up Function

In case of emergency stop or servo alarm, a machine travel amount is reflected on an NC unit internal position. For this reason, automatic operation is enabled after resetting the emergency stop or servo alarm, even if you do not have to perform zero point return.

In case of speed feedback or position feedback alarm, however, an actual machine position and the NC unit internal position do not match, because the follow-up function does not work properly.

18. MANUAL OPERATION

18-1 Manual Continuous Feed

With the axial feed switch being pressed in Jog mode, manual continuous feed is performed.

Feed rates are as follows:

(1) Jog feed

Jog feed rate can be changed over into 24 stages through use of the switch. Speed in 24 stages is set with parameters.

(2) Manual rapid

When jog feed is executed as the rapid traverse button being pushed, manual rapid traverse is available.

18-2 Manual Pulse Generator

The machine is capable of fine feed by means of the pulse generator on the machine operation panel. One rotation of the pulse generator generates 100 pulses. You can select a scale factor of x 1, x 10, or x 100 by a signal from the machine.

19. AUTOMATIC OPERATION

19-1 Program Number Search

An 4-digit program number following O can be searched for from the data in the Program screen.

19-2 Sequence Number Search

A sequence number can e searched for in the program currently selected from the data in the Program screen.

19-3 Feedhold

All axes can be stopped temporarily. Pressing the CYCLE START button restarts feeding the axes. Prior to restarting axis feed, you can allow intervention by manual operation in the manual mode.

20. PROGRAM TEST FUNCTIONS

20-1 Machine Lock

In the machine lock mode, the machine does not move, but the position display is updated as if the machine were moving.

The machine lock ON/OFF is not possible during auto operation. If you dare do it, it causes an alarm.

20-2 Dry Run

If the DRY RUN switch is turned on, the machine operates at a dry run rate instead of a programmed cutting feed rate. The cutting feed rate or dry run rate, whichever maximum value is greater, is executed.

20-3 Single Block

Program commands can be executed block by block.

21. DISPLAY AND SETTING

21-1 Machining End Notice

Input a scheduled program end time. When the machining time reaches the scheduled end time, a signal is output to an external device.

21-2 Run Hour Display

Machine run hours are displayed in the format of hours:minutes:seconds. Display is made by each of the functions including the expected ending, working time, cutting time, lap T, and date/time.

21-3 Work Count Function

The number of machined workpieces can be counted by the M12 command. By setting the number of workpieces beforehand, a signal is output to the machine when reaching the prescribed number of workpieces.

22. PART PROGRAM STORAGE & EDITING

22-1 Part Program Storage & Editing

The contents of the NC tape can be stored and edited. Relevant operations include deletion, alteration, and insertion. Range editing is allowed by expanded part program editing. Use of backgrounding allows you to edit another program during automatic operation.

Tape storage length	: 1,000 m/directory
Registered programs	: 200 programs/directory
Directory	10 directorys, 100 directory (option)
Total	10000 m 2000 programs, 100000 m 20000 programs
	(option)

22-2 Part Program Comparison

The program registered in the memory is compared with the one in the tape.

23. DIAGNOSTIC FUNCTIONS

23-1 Self Diagnostic Function

This function makes various checks.

The signals exchanged between the machine and NC unit can be confirmed on the screen.

23-2 Alarm Diagnosis

If the CNC has any error, it displays its corresponding alarm number and message.

24. DATA INPUT AND OUTPUT

24-1 Input/Output Interface (RS-232C)

This function allows you to output the programs, tool offset amounts, parameters, etc. memorized in the memory to an external device, and input the data from the external device. A device equipped with the RS-232C interface is available as an external device.

25. SAFETY FUNCTIONS

25-1 Emergency Stop

An emergency stop cancels all the commands and stops the machine instantaneously.

25-2 Overtravel

When the machine reaches a stroke end, a relevant signal is received, the axies are stopped instantaneously, and an overtravel alarm is indicated.

25-3 Interlock

There are two kinds of axis interlocks; all axes interlock, individual axis interlock. If the interlock is applied while moving the axis, the machine will be decelerated to stop. If an interlock signal is canceled, the machine will be accelerated to resume operation.

25-4 Stored Stroke Limit 1

Stored stroke limit 1 assumes the outside of the area set by a prameter to be a prohibited area.

25-5 Stored Stroke Limit 2 and 3 (G22, G23)

Use this function when you want to ensure that a tool will not enter a non-cutting area. Set stored stroke limit-2 with a parameter whether the inside or outside of the set area should be prohibited. Stored stroke limit-3 assumes the inside of the set area to be a prohibited area.

Use a G-code to enable/disable stored stroke limit-2.

- · G22: Enable
- · G23: Disable

(Stored stroke limit-3 is enabled regardless of the G-code)

25-6 Stroke Check Before Move

This function checks whether or not specified end point coordinates enter a stored stroke limit area before a move command in the program block.

III. OPERATION

- III. I Basic Machine Operation
- III. II Screen Operation

III. I Basic Machine Operation

- 1. Manual Operation
- 2. Automatic Operation
- 3. Operation Related to Safety
- 4. NC Operation keys
- 5. Quick Tool Setter (Q Setter)
- 6. Q Setter Barrier
- 7. Q Setter Repeat Function
- 8. Simple Jaw Edge Forming Function

1. Manual Operation

The machine can be manually operated by using the switches on the machine operation panel.

1-1 Jog Feed

The machine can be operated continuously by manual operation.

(1) Select the mode selector switch "JOG".



(2) Select the feed rate.



(3) Select the axis you want to move.



The machine moves in the direction of the selected axis.

- Note 1) When multiple axes are selected, those axes move all simult aneously.
- Note 2) When the axis has been selected before selecting the JOG mode, the machine does not move even if the mode is changed to JOG. Select the axis newly.

1-2 Manual Reference Point Return

The machine can be returned to the reference point by manual operation.

(1) Select the mode selector switch "JOG".



(2) Select the rapid traverse override.



(3) Select "ZERO RETURN".



The machine moves at the rapid traverse rate toward the reference point for each axis.

(4) When the machine returns to the reference point, the reference point return lamp gets illuminated.

1-3 Rapid traverse

The machine can be rapid traversed continuously by manual operation.

(1) Select the mode selector switch "JOG".



(2) Select the rapid traverse override.



(3) Select the axis you want to move, and "RAPID" simultaneously. The machine moves in the direction of the selected axis at the rapid traverse rate.

Note 1) Same as Notes for Jog Feed

1-4 Manual Handle Feed

The machine can be finely fed by turning the manual pulse generator.

(1) Select the mode selector switch "HANDLE".



(2) Select the handle axis.



(3) Select a handle magnification.



(4) Turn the handle.



- Note 1) Do not turn the manual pulse generator so quickly. If so done, the machine may not stop immediately after turning the handle, or the scale and the travel amount may not coincide with each other.
- Note 2) If the magnification "x 100" is selected and the handle is turned very quickly, the machine moves at a rate close to the rapid traverse rate. If you then stop the machine suddenly, it may be shocked.
- Note 3) In some cases, the mode selector switch "HANDLE" of (1) many not be provided, where Handle mode is selected by handle axis selection of (2).

2. Automatic Operation

2-1 Automatic Mode

- (1) Memory operation
 - (a) Store the program in the memory in advance.
 - (b) Select the program you want to run.
 - (c) Select the mode selector switch "AUTO".



(d) Press the CYCLE START button.



CYCLE START

Pressing this button stars automatic operation and turns on the CYCLE START lamp.

- (2) MDI operation
 - (a) Select the mode selector switch "MDI".



- (b) Input the program into the MDI operation buffer memory. The commands for multiple blocks can be input into the MDI operation buffer memory from the CRT/MDI panel. The program can be edited in the same manner as editing that stored in the memory.
- (c) Press the CYCLE START button. Automatic operation starts and the CYCLE START lamp gets illuminated.

2-2 Selecting the Run Program

- (1) Program No./Sequence No. search
 - (a) Select the mode selector switch "MEMORY".
 - (b) Display the Overall screen. (The Program screen will also do.) When any other screen than the Overall screen is displayed, press the > key to display the Overall screen.
 - (c) Press the O key in case of program number search, and press the N key in case of the sequence number search.
 - (d) Then, enter the program number or sequence number you want to search for, and press the cursor move key.
 - (e) A program or sequence number search is executed.

- (2) Rewind
- (a) Select the mode selector switch "EIDT".
- (b) Display the Overall screen. (The Program screen will do.)
- (c) Press the RESET key of the NC unit.
- (d) Select the mode selector switch "MEMORY".
- (3) Part program storage length and registered programs

Tape storage length	1000m/directory
Registered programs	100 programs/ directory
Directory	10 directories
	100 directories (option)
Total	1000m 1000 programs
	100000m 10000 programs (option)

2-3 Stopping the Automatic Operation

There are two methods to stop automatic operation; one is to insert a stop instruction (M00, M01, M02, or M30) in the program in advance at which you want it to stop, and the other is to press the button (FEEDHOLD or RESET) on the operation panel.

(1) Program stop (M00)

If the block where M00 has been specified is executed, automatic operation stops and execution does not proceed to the next block. The model information so far is all saved. Pressing the PROGRAM CYCLE START button restarts automatic operation.

(2) Optional stop (M01)

If the block where M01 has been specified is executed, automatic operation stops and execution does not proceed to the next block. However, this is true only when the OPTIONAL STOP switch on the machine operation panel in turned on.

- (3) Program end (M02, M30)
 - (a) Indicates the end of the main program.
 - (b) Stops automatic operation and places the machine in the reset mode.
 - (c) M02 and M30 return the program to its beginning.

2-4 Dry Run

This function enables a dry run speed, ignoring the feed rate specified with the program. ON/OFF is done on the test run screen.

2-5 Single Block

The single block function stops the machine after executing one block. Turn on the SINGLE BLOCK switch.



This causes the machine to stop after executing one block. Pressing the PROGRAM CYCLE START button stops the machine after executing the next block.

2-6 Override

For details related to the override function, refer to the instruction manual for the machine.

(1) Feed rate override

With the switch on the machine operation panel, an override of 0 % to 200 % can be applied to feed per minute (G98) and feed per revolution (G99).

(2) Rapid traverse override

The override selected with the switch on the machine operation panel can be applied to the rapid traverse rate.

(3) Feed rate override cancel

With a signal from the machine side, the feed rate override and automatic rapid traverse override can be fixed at 100 %.

3. Operation Related to Safety

3-1 Emergency stop

Pressing the EMERGENCY STOP button on the machine operation panel can stop the machine immediately.

EMERGENCY STOP



This switch is locked by pressing and released by turning the right.

- Note 1) Emergency stop shuts off a current to the motor.
- Note 2) The NC unit is reset to warn you of an emergency stop.
- Note 3) Before releasing the EMERGENCY STOP switch, it is necessary to eliminate a trouble cause.

3-2 Overtravel

When the tool moves over the stroke end set by the limit switch of the machine or enters the disabled area of the set stored stroke limit, an alarm is displayed and the moving axis is decelerated to a stop.

In this case, move the tool manually in a safe direction, press the reset key, and cancel the alarm.

4. NC Operation keys

Table 4-0

No.	Name	Description
1	RESET key	Press this key when resetting the CNC unit in order to
		reset an alarm, and so on.
2	Function keys	When the function menu is displayed at the bottom of
		the CRT, there are the keys to select the menu.
3	Maintenance Menu Display key	Pressing this key in the overall screen switches to the
		maintenance menu.
4	RETURN key	Press this key when you want to return to the Overall
		screen.
5	AUX. key	Press this key when you want to move the cursor of
		the overall screen to another window.
6	HELP key	
\bigcirc	Address and Numerical keys	Used to input the alphabet, numbers, etc.
8	SHIFT key	There are some address keys which have 2 characters
		marked on them. If you press the address key after the
		SHIFT key, upper left character is input.
9	INPUT key	If the address or numerical key is pressed, it is input
		into the key input buffer once, and then, displayed on
		the CRT. Press the INPUT key when actually setting
		the data input into the key input buffer.
10	CANSEL key	Press this key when deleting the characters or
		symbols input into the key input buffer.
1	ORIGIN key	This key is used to clear the Plot screen.
12	DELETE, ALTER and INSERT	Used to perform deletion, alteration and insertion in
	keys	editing the program.
13	Cursor key	There are 4 keys which are used to move the cursor
		up/down and right/left.
14	Page key	There are 2 keys which are used to page in the
		forward and backward directions.
15	OPER. GUIDE	Press this key when you want to display in the
		Operation Guide screen.
16	MACHINE key	In case of a multiple series machine, use this key to
		switch the series to be displayed.
$\boxed{1}$	MENU SELECT key	Pressing this key in the overall screen switches to the
		menu to display a small screen.


5. Quick Tool Setter (Q Setter)

5-1 Outline

A tool offset amount can be automatically written by simply bringing the tool nose into contact with the touch sensor manually.

5-2 Operation Method

- (1) Set the quick tool setter.
 - (a) Set the tool setter. (Fig. 5-2(b))
 - (b) Select the MANUAL mode.
 - (c) A screen display is automatically switched to the Tool (Offset) screen; "Q SETTER" is displayed to inform you that the system is ready. (Fig. 5-2(a)) When initial reference point return has not been completed, setting the tool setter results in an alarm.
- (2) Call the tool for which you want tool offset.
- (3) Select and confirm the tool offset number.

The tool offset number is consistent with the called tool number, and the cursor moves automatically. When the cursor is moved with the key, the cursor-indicated tool offset number is selected.

- (4) Bring the tool nose closer to the tool setter.
 - (a) When bringing it closer by jog feed, select the JOG mode and presa the X- or Z-axis direction selector switch.
 - (b) When bringing it closer by handle feed, select the HANDLE mode, and then, the X or Z axis. Next, set a handle magnification to ×100 and turn the handle.
- (5) Position the tool nose to the center of the sensor by handle feed. (Fig. 5-2(c))
- (6) Apply the tool tip to the touch sensor in jog feed.The jog feed rate is held at the constant rate set with a parameter. Maintain the tool tip in continuous jog feed by not bringing it close to or keeping it away from the touch sensor.
- (7) Bringing the tool nose into contact with the touch sensor inputs a tool offset amount automatically. When the tool nose comes into contact with the sensor, the axis stops, emitting a "beep" sound. (Fig. 5-2(d))
- (8) Put away the tool nose from the touch sensor by more than a retouch return amount (parameter), and bring it into contact again. Repeating this, confirm the tool offset amount shown on the screed. (Fig. 5-2(e))
- (9) Put away the tool nose to a safety position from the touch sensor. (Fig. 5-2(f))
- (10) Put away the tool nose to the position where the tool can be called.
- (11) Obtain the tool offset amount of the next tool.Repeating the above steps (2) through (10), obtain the tool offset amount of each tool sequentially.
- (12) House, the tool setter. (Fig. 5-2(g)) The display of "Q SETTER" disappears. While in axis shifting, do not store the tool setter.

TOOL OFFS	ET		00000
JOG RESET	DryRun	Lock	Chuck OUT Q SETTER NOOOO
001 TURN X F B. INT.FACE X F R F T F H F	GEOM 110.000 0.800 3 0.000	U 0.000 W 0.000 Q 0.000 J 0.000	OO4 TURN GEOM WEAR ROUGH T.D. X -15.780 U 0.000 Z 111.510 ₩ 0.150 R 0.000 Q 0.000 T 1 H 0.000 J 0.000
	GEOM 0.000 87.780 0.000 4 0.000	WEAR U 0.000 W 1.000 Q 0.000 J 0.000	005 TURN GEOM WEAR NECKINK OD X 0.000 U 0.000 Z 0.000 W 0.000 R 0.400 Q 0.000 T 3 H 5.000 J 0.000
003 TURN X ROUGH O.D. Z R R T H H	GEOM 2.000 2.000 2.000 2.000	U 0.000 W -0.100 Q 0.000 J 0.000	ABSOLUT MACHINE X 298.000 X 0.000 Z 500.100 Z 0.000 C 246.933 C 246.933
1 TYPE	NAME TIP	FORH /4 /5	0-SETTER DATA REPEAT /6 CLEAR /7 /8 /9 /0

Fig. 5-2(a) Q Setter Screen



Fig. 5-2(b)









Fig. 5-2(e)

Fig. 5-2(d)



5-3 Tool Nose Point Interlock

Bringing the tool into contact with the sensor stops the axis and checks the tool nose point. When the contact directions and tool nose point conditions shown in the table below are not met, an interlock is applied to an input of tool offset amount to disable a write.

The tool nose point for tool nose point interlock is that for the offset number currently selected.

Tool Nose Point Contact Direction	1	2	3	4	5	6	7	8	9	0	
+ X	×	×	0	0	×	×	×	0	0	0	The contact
- X	0	0	×	×	×	0	×	×	0	0	and move
+ Z	×	0	0	×	×	×	0	×	0	0	
- Z	0	×	×	0	0	×	×	×	0	0	

Table 5-3

 \bigcirc : Write enabled

 \times : Write disabled

Note) To enable this interlock, it is necessary to set "1" in the bit 4 of H_PARA [3].

5-4 Related Parameters

(1) Parameters for the tool (offset) memory
With signed parameters, set the distances from the reference tool nose position to the respective contact surfaces at the machine origin.
MD62200[4], [5] Q setter contact surface amount on the "+" side (inside)
MD62200[6], [7] Q setter contact surface amount on the "-" side (outside)



Fig. 5-4 Parameters for the Tool (offset) Memory

Calculate the tool offset amount by the following formula.

Tool offset amount = Skipped machine coordinate value – Q-setter contact surface amount parameter (2) Tool nose point interlock

Bit 4 of No.8003 Q setter interlock

0: Disabled

1: Enabled

(3) Retouch return amount MD6200[2] Retouch return amount of the setters

5-5 Related Alarms

No.67114 A tool nose point interlock is being applied with the Q setter.

6. Q setter barrier

6-1 Outline

After measuring the tool compensation amount using the quick tool setter function, if the tool is made to escape in the direction of the reference point, it may touch the touch sensor, depending on the tool diameter.

For instance, if the tool shape is an shown in Fig. 6-1, after measuring the tool compensation amount by means of the sensor in the X+ direction, if the tool is immediately returned to the reference point from this position, the tool nose may touch the touch sensor.

To prevent such occurrences, there is a function that sets up a barrier area near the touch sensor and prohibits motions such as return to the reference point when the nose position has entered this area. Thus, this function prevents damage to the touch sensor. However, it is based on the condition that the offset value is properly entered for both X and Y directions.



Fig. 6-1 Outline of Q Setter Barrier

6-2 Description of the function

(1) When the tool setter arm descends and enters the Q setter mode, the control equipment checks whether the tool is within the Q setter barrier area by performing the calculations given below.

X value of machine coordinate system \leq MD6200[8] +Tool compensation amount X AND

Z value of machine coordinate system \leq MD6200[9] +Tool compensation amount Z when the above equations are satisfied, the control equipment judges the tool to be within the barrier area. (Fig. 6-2)

The tool compensation amount is calculated as the sum of the shape of compensation number currently selected and the wear.

(2) When the tool is in the barrier area, the signal given below is output to the PLC.

PLC address

Q setter barrier area in-signal \$A_OUT[26] (DB10.DBX192.1)

Using this signal, process the reference point return interlock and message display with in the barrier area.

Return the arm of the tool setter. When the Q setter mode is terminated, this signal becomes "0" even if the tool is within the barrier area.



Fig. 6-2 Q Setter Barrier Area

6-3 Precautions

- (1) Positions above the barrier line is taken as positions within the barrier area.
- (2) After tool replacement, check will be performed using the previous tool compensation amount, until the new tool compensation amount is written.

6-4 Related parameters

- (1) Q setter barrier value
 - MD6200[8], [9] Q setter barrier value (X, Z)
- (2) Q setter barrier check

Bit 7 of No.8003

Q setter barrier check is an given below.

- 0: Ineffective
- 1: Effective

7. Q Setter Repeat Function

7-1 Outline

Through a simple operation, you can repeatedly perform measurement on tip changing of a tool which has already been subject to measurement in Q setter.

7-2 Operation

- ① Push F6/Q-SETTER REPEAT on Tool (Compensation) page, Window page for Q setter repeat is displayed.
- ② Set Feed mode.
- ③ Changing a tip, perform indexing of the turret to a measurement position. At this time both the cursor inside Turret State on the left side of the page and the compensation data at the top right-hand corner of the page change as linking to the turret face.
- ④ Bring out the Q setter arm.
- 5 Push F4/START.

If the tool has been already subject to measurement in Q setter (with the data already existing in the measurement position on the page), measurement by Q setter repeat is started. When the tool touches the sensor, a measured value is written in compensation data. The touch mark is displayed on the picture indicating a measurement position.

If measurement has not yet been performed in Q setter, alarm takes place.



Fig. 7-2 Q Setter Repeat Screen

7-2-1 Function Key

F4/ Repeat Measurement Start	:	"OK? Y-Yes N-No" message appears. With $ Y $,
		measurement starts.
F5/ Repeat Measurement Halt	:	Measurement operation is stopped.
F6/ Function Return	:	Screen display returns to Tool Compensation.
F7/ Data Delete	:	On appearance of a window, select either "One Meas. Spot"
		or "Whole Meas. Spot" and push INPUT . "OK? Y-Yes, N-
		No" message appears. With $[Y]$, the measurement spots
		are deleted.

7-3 Working

The working patterns, as shown in Fig. 7-3(c) can be divided into 8 kinds according to the virtual nose points.

When Virtual Point 1, 2, 3, or 4 being assigned, both X and Z axes are subject to measurement. The order for measurement, in that case, is always Z to X axis.

When Virtual Point 0, 5, 6, 7, 8, or 9 being assigned, X or Z axis alone is subject to measurement. In this case, for compensation of the axis not being measured, compensation needs to be input manually beforehand. As for virtual nose points of tools, see Fig. 7-3(a).



Fig. 7-3(a) Virtual Nose Points of Tools

The following example describes the case when the virtual nose point is 1:(See Fig. 7-3(b))

(1)Shifted in rapid traverse from Start Point (PO) to Point 1 (PO).

(2)Shifted in rapid traverse from P1 to P2.

(3)Shifted in rapid traverse from P2 to P3.

(4)Shifted in feed speed from P3 to the end position (P4) to be touched.

(5)Shifted in feed speed from the point where touching and stopping have taken place.

(6)Shifted from P5 to P6 in rapid traverse.

(7)Shifted from P6 to P7 in rapid traverse.

(8)Shifted in feed speed from P7 to the end position (P8) to be touched.

(9)Shifted in feed speed from the touch-and-stop position to P9.

(10)Shifted from P9 to P10 in rapid traverse.

(11)Shifted from P10 to the start point (P11) in rapid traverse.



Fig. 7-3(b) Working with Virtual Nose Point 1





7-4 Precaution

- (1) When a tool has been changed, be sure to manually apply it to Q setter.
- (2) Apply it to Q setter only once.
- (3) Approaching, in rapid traverse, from the sensor to the place just before the clearance amount on approach, touch the sensor in the feed rate (mm/min).
- (4) Single block is held valid while in measurement operation.

(Re-started with F4/REPEAT START .)

- (5) When the measurement start point can touch the sensor, alarm takes place.
- (6) When the sensor has not been touched in measurement, alarm takes place after operation is over.
- (7) Threading tools, tip changing type drills, end mills, and other tools which are similar to these cannot be subject to measurement.
- (8) The measurement start point is any one position free from danger or touching the sensor.
- (9) When, in some operation patterns, an interference exists with a work, remove the work from the chuck.
- (10) When a large difference exists between the Q setter measurement and the work measurement dimension, adjust Q setter position on Maintenance page.
- (11) When the machine is provided with the Y-axis, it must be in the following conditions when starting Q-setter repeat.
 - The Y-axis is at the origin. (The ORIGIN lamp is ON)
 - The tool offset amount for the Y-axis is 0. (Both shape and Wear are 0)
- (12) The measuring spots are deleted in the following cases:
 - When Data Delete on the screen is effectuated.
 - When shape data for tool compensation volume and nose T have been input.

7-5 Relevant Parameters

- No.8003, #0 =0 Does not check the door close in the Q setter repeat.
 - =1 Checks the door close in the Q setter repeat.
 - #1 =0 Measurement time of the Q setter repeat is 1 time.
 - =1 Measurement times of the Q setter repeat are 3 times.
 - #2 =0 The touch signal check in the Q setter repeat is valid.
 - =1 The touch signal check in the Q setter repeat is invalid.
 - #3 =0 Measurement of a rotation tool in the Q setter repeat is not possible.
 - =1 Measurement of a rotation tool in the Q setter repeat is possible.
 - #4 =0 The Q setter interlock is invalid.
 - =1 The Q setter interlock is valid.
 - #7 =0 The Q setter barrier check is invalid.
 - =1 The Q setter barrier check is valid.
- MD62200[4] Q setter contact area + Side coordinate value X (mm) (set by the radius)
- MD62200[5] Q setter contact area + Side coordinate value Z (mm)
- MD62200[6] Q setter contact area Side coordinate value X (mm) (set by the radius)
- MD62200[7] Q setter contact area Side coordinate value Z (mm)
- MD62200[11] Thrusting amount of the Q setter repeat (mm)

MD62200[12] Clearance amount on approaching for Q setter repeat (mm)
MD62200[13] Clearance amount for right-handed machine tool for Q setter repeat (mm)
MD62200[14] Clearance amount for left-handed machine tool for Q setter repeat (mm)
MD62210[0] The feed rate when having the Q setter repeat touch (mm/min).
MD62210[1] The return rate from the position the Q setter repeat touched (mm/min).

7-6 Relevant Alarms

- No.67100 An error occurred in the Q setter repeat.
- No.67124 No measurement has been performed in Q setter.
- No.67138 The touch signal was not entered in the Q setter repeat.
- No.67139 Measurement start point of Q setter repeat is not correct.
- No.67149 Cannot measure the rotary tool with Q-setter repeat.

8. Simple Jaw Edge Forming Function

8-1 Outline

With "Edge shape" "Working Conditions" being input according to the guidance on the page and the start button being pushed, raw edge machining starts.

8-2 Operation

- ① Index the tool used for raw edge forming to the machining position.
- ② Pushing F6/JAW on the page of the work coordinate system
 - (General \rightarrow F4/WORK OFFSET), display Window page for raw edge forming.
- ③ Select either outer jaw or inner jaw forming by using F4/OUTER JAW or F5/INNER JAW.
- ④ Prepare the section where a core bar is fitted and mount it properly.
- (5) Input an edge configuration and working conditions.
- Turning the spindle in Manual mode, shift the tool to the edge position.
 With F3/JAW END SURFACE pushed, "Jaw end surface position setting? Y-Yes/N-No" is displayed. With Y, set the jaw end position.
- Pushing F9/CUT PATH CHECK in MDI mode, check the locus of a working program. If not in MDI mode, "Set MDI mode" message is displayed. While in locus checking, Dry-Run and Machine Lock ON state are held effective. The operation panel lamps, however, do not lit up. Also, no MST code is output.

The coordinate system (tip position) is brought to presetting on completion of locus checking or by resetting while in checking.

- (8) Perform zero returning as paying attention not to cause interference.
- 9 Pushing the start button in MDI mode, execute a working program of raw edge forming.



Fig. 8-2(a) Jaw Edge Forming (Outer Jaw)

SOFT JAW FORMING						(00000
NDI RESET	DryRun 🖬 L	.ock Ch	uck OUT				N0000
INNER							
$\Box \cap$	DIMENSION	MACHINING					
	A 130.000 B 10.000 C 220.000 D 205.000 E 20.000 T 0.030 F 0.500 G 0.000 H 1.000 J 13.000 K 0.000	CUTTING SPEED SPINDLE SPEED FEED SPEED CUT-IN F. AMOUN CHUCK O SOFT ID HI	R. F. F. F. R. F. T. F. UT 22 UT 22 UT 24 CH	100 120 245 294 0.150 0.100 2.000 0.200 20.000 41.000 39.000			
					TOOL NO	SE POSITION	
<pre> description >>- The outer diam </pre>	eter of 1st ste	ep.			X Z	298. (0. ()00)00
			Jav	end c	omp.	Tool 030()
A =							
SET UP	2 SURFAC /3 JAW /4	INNER E JAW /5	XIT D/ ZIT /6 CLE	ATA RE EAR /7	SET CU 78 CH	T PATH DRAW ECK /9 /	

Fig. 8-2(b) Jaw Edge Forming (Inter Jaw)

8-3 Function Keys

F2/SET UP	:	The Setup window appears and allows you to specify the spindle
		speed and turret indexing.
F3/JAW END SURFAC	:	"Jaw End Surface Position Setting? Y-Yes/N-No" message is
		displayed. Set with Y .
		The Z coordinate value of the (soft jaw) tool nose position is
		cleared to 0. (The Z coordinate value for the relative coordinate
		system.)
F4/OUTER JAW	:	Outer Jaw Forming page is selected.
F5/INNER JAW	:	Inner Jaw Forming page is selected.
F6/EXIT	:	Work Coordinate System page is returned.
F7/DATA CLEAR	:	"Edge Configuration and Working Condition Erased? Y-Yes/N-No"
		message appears. Select $[Y]$ to clear.
F8/RESET	:	Soft jaw forming is ended. Push this to return to normal work. The
		jaw end surface setting position is cleared.
F9/CUT PATH CHECK	:	A locus of a working program is drawn.
F0/JAW CONTOUR DRA	٩W	NG: You can turn, enlarge and contract the picture of the jaw
		contour.

8-4 Jaw Configuration And Machining Conditions

(1) JAW CONFIGURATION

The symbols of jaw configurations indicate the following:

- A : Inner diameter for 1st stage
- B : Depth for 1st stage
- C : Core metal diameter
- D : Inner diameter for 2nd stage
- E : Depth for 2nd stage (With 0 setting, one-stage jaw is obtained.)
- T : Grip part taper amount
- F : Necking depth
- G : Max. Value of stock allowance
- H : Setting of chamfering amount
- I : Setting of necking width (clearance)
- J : Bolt position 1
- K : Jaw extrusion from chuck outer face is input in +/-. (Chuck outer diameter taken as reference)

(2) MACHINING CONDITIONS

Cutting speed	Rough:	Cutting speed for rough cutting (m/min)
Cutting speed	Finish:	Cutting speed for finishing (m/min)
Number of revolution	Rough:	Number of revolution for rough cutting (rpm)
		(Automatically calculated from cutting speed.)
Number of revolution	Finish:	Number or revolution for finishing (rpm)
		(Automatically calculated from cutting speed.)
Feed speed	Rough:	Feed speed for rough cutting (mm/rev)
Feed speed	Finish:	Feed speed for finishing (mm/rev)
Cut depth	Rough:	Depth of cut for rough cutting (mm)
		(With 0 setting, finishing alone is performed.)
Finishing Allowance	Finish:	finishing allowance for finishing (mm)
		(With 0 setting, finishing alone is performed.)

8-5 Precaution

- (1) Before executing soft jaw forming, set a jaw end surface position. When locus checking or soft jaw forming is executed without a edge position being set, warning takes place.
- (2) Clamp max. spindle rpm is Soft Jaw Forming mode to the parameter set value.
- (3) When E and D value is 0, it gets 1-stage edge.
- (4) When a locus is not clearly displayed, reduce speed with the feed speed switch.
- (5) In order to perform necking, pay attention to the tip shape.
- (6) When the machine is provided with the Y-axis, it must be in the following conditions when starting soft jaw forming.
 - The Y-axis is at the origin. (The ORIGIN lamp is ON)
 - The Y-axis tool offset amount for the Y-axis is 0. (Both shape and Wear are 0)

8-6 Relevant Parameters

(GUD)	(R	eference Values)
H_NAMA[35]	Feed rate magnification in unload cutting of soft faw formir	ng
H_NAMA[34]	Max. spindle rpm of soft jaw forming	(1000rpm)
H_NAMA[31]	Approach amount on finishing in soft jaw forming	(10.000mm)
H_NAMA[33]	Soft jaw forming clearance	(2.000mm)
H_NAMA[32]	Approach amount on clearance in soft jaw forming	

8-7 Relevant Alarms

No.66270	Soft jaw error
----------	----------------

Numerals following "#" tells details of the alarm as follows:

Table 8-7	Relevant Alarms
-----------	------------------------

#001	$A \leq 0$ (A: 1st stage inner dia./outer dia.)
#002	$B \leq 0$ (B: 1st stage depth)
#003	$C \leq 0$ (C: Core bar dia.)
#004	$D \leq 0$ (D: 2nd stage inner dia./outer dia.)
#005	$E \leq 0$ (E: 2nd stage depth)
#006	T < 0 (T: Grip part taper amount)
#007	F < 0 (F: Necking depth)
#008	G < 0 (G: Max. value of stock allowance)
#009	H < 0 (H: Chamfering amount)
#010	$I \ge 0$ (I: Necking width)
#011	C ≦ A (Core bar dia.≧ 1st stage inner dia.)
#012	$C \ge A$ (Core bar dia. ≤ 1 st stage outer dia.)
#013	$D \leq A$ (2nd stage \geq 1st stage inner dia.)
#014	$D \ge A$ (2nd stage ≤ 1 st stage outer dia.)
#015	$C \leq D$ (Core bar dia. \geq 2nd stage inner dia.)
#016	$C \ge D$ (Core bar dia. $\le 2nd$ stage outer dia.)
#017	$B \leq E$ (1st stage \geq 2nd stage depth)
#018	Chamfering is too large.
#019	Necking width is too large.
#020	Bolt interference has occurred.
#101	cutting rate (rough) ≤ 0
#102	cutting rate (finish) ≤ 0
#103	Feed rate (rough) ≤ 0
#104	Feed rate (finish) ≤ 0
#105	Depth of cut
#106	Finish amount <0
#107	Chuck outer diameter<0
#108	Bolt barrier: Jaw bolt hole pitch<0
#109	Bolt barrier: Bolt hole center<0
#110	Bolt barrier: Spot facing diameter<0
#111	Approach amount<0
#112	Clearance amount<0
#113	Relief amount<0
#114	Spindle clamp speed<0
#901	Jaw contour not determined.
#902	Starting up from other than the soft jaw forming screen.

8-8 Set Values for Standard Soft Jaws

8-8-1 Metric Specifications

(1) ST200, ST250

	Mod	el	ST2	200	ST2	250		
Item			Outer Jaw	Inner Jaw	Outer Jaw	Inner Jaw	Outer Jaw	Inner Jaw
Jaw	,	A	130.0 mm	130.0 mm	150.0 mm	150.0 mm		
Con	figuration	В	10.0 mm	10.0 mm	10.0 mm	10.0 mm		
		С	41.0 mm	220.0 mm	68.0 mm	254.0 mm		
		D	90.0 mm	205.0 mm	100.0 mm	240.0 mm		
		Е	20.0 mm	20.0 mm	20.0 mm	20.0 mm		
		Т	0.03 mm	0.03 mm	0.03 mm	0.03 mm		
		F	0.5 mm	0.5 mm	0.5 mm	0.5 mm		
		G	0.0 mm	0.0 mm	0.0 mm	0.0 mm		
		Н	1.0 mm	1.0 mm	1.0 mm	1.0 mm		
		Ι	1.5 mm	1.5 mm	1.5 mm	1.5 mm		
		J	13.0 mm	13.0 mm	15.0 mm	15.0 mm		
		К						
	Cutting Speed	Rough	100m/min	100m/min	100m/min	100m/min		
		Finish	120m/min	120m/min	120m/min	120m/min		
s	RPM	Rough	Automatically	Automatically	Automatically	Automatically		
itior			Calculated.	Calculated.	Calculated.	Calculated.		
puo		Finish	Automatically	Automatically	Automatically	Automatically		
ng c			Calculated.	Calculated.	Calculated.	Calculated.		
/orki	Feed Speed	Rough	0.15mm/rev	0.15mm/rev	0.15mm/rev	0.15mm/rev		
\$		Finish	0.10mm/rev	0.10mm/rev	0.10mm/rev	0.10mm/rev		
	Depth of Cut	Rough	2.0 mm	2.0 mm	2.0 mm	2.0 mm		
	Stock Allowance	Finish	0.2 mm	0.2 mm	0.2 mm	0.2 mm		
Soft	Jaw	Outer Dia.	220.0 mm	220.0 mm	254.0 mm	254.0 mm		
		Inner Dia.	41.0 mm	41.0 mm	68.0 mm	68.0 mm		
		Height	39.0 mm	39.0 mm	41.0 mm	41.0 mm		
Jaw	Jaw Bolt Hole Pitch H_NAMA[28]		25.0	mm	32.0	mm		
Bolt	Center Pos.							
from	Jaw Surface H_I	NAMA[29]	15.0	mm	16.0	mm		
Bolt	Spot Facing Dia. H	_NAMA[30]	19.5	mm	19.5	mm		

Table 8-8-1 Set Values for Standard Soft Jaws (Metric Specifications)

8-8-2 Inch Specifications

(1) ST200, ST250

Table 8-8-2 Set Values for Standard Soft Jaws (Inch Specifications)

Model		ST	200	ST	250			
	ltem		Outer Jaw	Inner Jaw	Outer Jaw	Inner Jaw	Outer Jaw	Inner Jaw
Jaw		Α	5.00 inch	5.00 inch	6.00 inch	6.00 inch		
Conf	iguration	В	0.40 inch	0.40 inch	0.40 inch	0.40 inch		
		С	1.60 inch	8.66 inch	2.68 inch	10.0 inch		
		D	3.50 inch	8.00 inch	4.00 inch	9.50 inch		
		E	0.80 inch	0.80 inch	0.80 inch	0.80 inch		
		Т	0.001 inch	0.001 inch	0.001 inch	0.001 inch		
		F	0.02 inch	0.02 inch	0.02 inch	0.02 inch		
		G	0.00 inch	0.00 inch	0.00 inch	0.00 inch		
		Н	0.04 inch	0.04 inch	0.04 inch	0.04 inch		
		I	0.06 inch	0.06 inch	0.06 inch	0.06 inch		
		J	0.51 inch	0.51 inch	0.59 inch	0.59 inch		
		К						
	Cutting Speed	Rough	300ft/min	300ft/min	300ft/min	300ft/min		
		Finish	400ft/min	400ft/min	400ft/min	400ft/min		
s	RPM	Rough	Automatically	Automatically	Automatically	Automatically		
itior			Calculated.	Calculated.	Calculated.	Calculated.		
puo		Finish	Automatically	Automatically	Automatically	Automatically		
ng o			Calculated.	Calculated.	Calculated.	Calculated.		
orki	Feed Speed	Rough	0.006in/rev	0.006in/rev	0.006in/rev	0.006in/rev		
3		Finish	0.004in/rev	0.004in/rev	0.004in/rev	0.004in/rev		
	Depth of Cut	Rough	0.08 inch	0.08 inch	0.08 inch	0.08 inch		
	Stock Allowance	Finish	0.008 inch	0.008 inch	0.008 inch	0.008 inch		
Soft	Jaw	Outer Dia.	8.66 inch	8.66 inch	10.00 inch	10.00 inch		
		Inner Dia.	1.60 inch	1.60 inch	2.68 inch	2.68 inch		
		Height	1.54 inch	1.54 inch	1.60 inch	1.60 inch		
I								
Jaw	Bolt Hole Pitch H_I	NAMA[28]	1.00	inch	1.26	inch		
Bolt	Center Pos.							
from	Jaw Surface H_N	NAMA[29]	0.60	inch	0.63	inch		
Bolt	Spot Facing Dia. H	_NAMA[30]	0.77	inch	0.77	inch		

8-9 Operation Of Simple Soft Jaw Forming Function

(1) Outer 1 stage jaw

Table 8.9 (a) Operation of simple soft jaw forming function (outer 1 stage jaw)

Process	Command	Description
1	G18	Z-X plane selection.
2	G99 Fxx	Every revolution, feed speed of roughing.
3	G96 Sxx	Constant surface speed, cutting speed of roughing.
4	G50 Sxx	Spindle rpm clamp, soft jaw forming spindle max. rpm (H_NAMA[34])
5	M03	Spindle forward rotation.
6	G00 Xxx Zxx	Approach to the point immediately before the jaw end surface (Jaw end surface + H_NAMA[31])
7		When cut-in amount=0, no roughing \rightarrow to process 21.
8		Roughing end position is reached in the next cut-in \rightarrow to process 16.
9	G01 Xxx Fxx	Deepen the cut-in to X by 1 cut (D)/dry cutting speed.
10		No dry cutting section \rightarrow to process 12.
11	G01 Zxx	Dry cutting.
12	G01 Zxx Fxx	Rough cutting/feed speed of roughing.
13	G01 Uxx Wxx Fxx	Relief (Relieve amount = H_NAMA[33])
14	G00 Zxx	Return.
15		\rightarrow to process 8.
16	G01 Xxx Fxx	To the roughing last X position.
17	G01 Zxx Fxx	To the jaw end surface/feed speed of roughing.
18	G01 Xxx Zxx	Cutting of taper.
19	G01 Uxx Wxx Fxx	Relief.
20	G00 Zxx	Return.
21	G99 Sxx	Surface speed constant control/cutting speed of finishing.
22	G01 Xxx Fxx	Approach to finishing.
23	G01 Zxx Fxx	To jaw end surface/feed speed of finishing.
24	G01 Xxx Fxx	Chamfering.
25	G01 Xxx Zxx	Cutting of taper.
26		No necking \rightarrow to process 31.
27	G96 Sxx	Constant surface speed control/cutting speed of roughing.
28	G01 Xxx	Necking.
29	G01 Zxx	Necking.
30	G96 Sxx	Constant surface speed control/cutting speed of finishing.
31	G01 Uxx Wxx Fxx	Relief.
32	G01 Xxx	Relief.
33	G01 Zxx	Approach to cutting of end surface.
34	G01 Xxx Fxx	Cutting of end surface/feed speed of finishing.
35	G01 Uxx Wxx Fxx	Relief.
36	G00 Xxx Zxx	Return to front of jaw end surface.
37	G00 Xxx Zxx	Return to starting point.
38	M05	Spindle stop.
39	G97	Constant surface speed cancel.
40	M30	Soft jaw forming end.

(2) Outer 2 stage Jaw

Table 8-9 (b) Operation o	f simple soft jaw formi	ing function (outer 2	2 stage jaw)
---------------------------	-------------------------	-----------------------	--------------

Process	Command	Description
1	G18	Z-X plane selection.
2	G99 Fxx	Every revolution, feed speed of roughing.
3	G96 Sxx	Constant surface, cutting speed of roughing.
4	G50 Sxx	Spindle rpm clamp, soft jaw forming spindle max. rpm (H\NAMA[34]).
5	M03	Spindle forward rotation.
6	G00 Xxx Zxx	Approach to the point immediately before the jaw end surface (Jaw end surface + H_NAMA[31]).
7		When cut-in amount=0, no roughing \rightarrow to process 32.
8		Roughing end position Is reached in the next cut-in \rightarrow to process 22.
9	G01 Xxx Fxx	Deepen the cut-in to X by 1 cut (D)/dry cutting speed.
10		No dry cutting section \rightarrow to process 12.
11	G01 Zxx	Dry cutting
12	G01 Xxx Fxx	Rough cutting/feed speed of roughing.
13		When X current position = D - finishing amount, \rightarrow to process 18.
14		When X current position < D - finishing amount, \rightarrow to process 19.
15		When cutting of 2nd stage taper is finished, \rightarrow to process 19.
16	G01 Xxx	To the height of 2nd stage taper.
17	G01 Zxx	To the starting point of 2nd stage taper.
18	G01 Xxx Zxx	Cutting of 2nd stage taper.
19	G01 Uxx Wxx Fxx	Relief.
20	G00 Zxx	Return.
21		\rightarrow to process 8.
22	G01 Xxx Fxx	To the roughing last X position.
23	G01 Zxx Fxx	To jaw end surface/feed speed of roughing.
24	G01 Xxx Zxx	Cutting of taper.
25	G01 Uxx Wxx Fxx	Relief.
26		When cutting of 2nd stage taper is finished, \rightarrow to process 31.
27	G01 Xxx	To the height of 2nd stage taper.
28	G01 Zxx	To the starting point of 2nd stage taper.
29	G01 Xxx Zxx	Cutting of 2nd stage taper.
30	G01 Uxx Wxx Fxx	Relief.
31	G01 Zxx	Return
32	G96 Sxx	Constant surface speed control/cutting speed of finishing.
33	G01 Xxx Zxx	Approach to finishing.
34	G01 Zxx Fxx	To jaw end surface/feed speed of finishing.
35	G01 Xxx Zxx	Chamfering.
36	G01 Xxx Zxx	Cutting of taper.
37		No necking \rightarrow to process 42.
38	G96 Sxx	Constant surface speed control/cutting speed of roughing.
39	G01 Xxx	Necking.
40	G01 Zxx	Necking.

41	G96 Sxx	Constant surface speed control/cutting speed of finishing.
42	G01 Uxx Wxx Fxx	Relief.
43	G01 Xxx	Relief.
44	G01 Zxx	Approach to end surface cutting.
45	G01 Xxx Fxx	End surface cutting/feed speed of finishing.
46	G01 Uxx Wxx Fxx	Relief.
47	G01 Xxx Fxx	Approach to 2nd stage chamfering.
48	G01 Zxx Fxx	To 2nd stage end surface/feed speed of finishing.
49	G01 Xxx Zxx	2nd stage chamfering.
50	G01 Xxx Zxx	Cutting of 2nd stage taper.
51		No necking \rightarrow to process 56.
52	G96 Sxx	Constant surface speed control/cutting speed of roughing.
53	G01 Xxx	Necking.
54	G01 Zxx	Necking.
55	G96 Sxx	Constant surface speed control/cutting speed of finishing.
56	G01 Uxx Wxx Fxx	Relief.
57	G01 Xxx	Relief.
58	G01 Zxx	Approach to end surface cutting.
59	G01 Xxx Fxx	End surface cutting/feed speed of finishing.
60	G01 Uxx Wxx Fxx	Relief.
61	G00 Xxx Zxx	Return to the front of jaw end surface.
62	G00 Xxx Zxx	Return to the starting point.
63	M05	Spindle stop.
64	G97	Constant surface speed control cancel.
65	M30	Soft jaw forming end.

(3) Inner 1 stage Jaw

Table 8-9 (c) Operation of simple soft jaw forming function (inner 1 stage jaw)w)

Process	Command	Description
1	G18	Z-X plane selection.
2	G99 Fxx	Every revolution, feed speed of roughing.
3	G96 Sxx	Constant surface speed, cutting speed of roughing.
4	G50 Sxx	Spindle rpm clamp, soft jaw forming spindle max. rpm (H_NAMA[34])
5	M03	Spindle forward rotation.
6	G23	Stroke limit check 2,3 off.
7	G00 Xxx Zxx	Approach to the front of jaw end surface (Jaw end surface + H_NAMA[31])
8		When cut-in amount=0, no roughing \rightarrow to process 22.
9		Roughing end position is reached in the next cut-in \rightarrow to process 17.
10	G01 Xxx Fxx	Deepen the cut-in to X by 1 cut (D)/dry cutting speed.
11		No dry cutting section \rightarrow to process 13.
12	G01 Zxx	Dry cutting.
13	G01 Zxx Fxx	Rough cutting/feed speed of roughing.
14	G01 Uxx Wxx Fxx	Relief (Relieve amount = H_NAMA[33])
15	G00 Zxx	Return.
16		\rightarrow to process 9.
17	G01 Xxx Fxx	To the roughing last X position.
18	G01 Zxx Fxx	To the jaw end surface/feed speed of roughing.
19	G01 Xxx Zxx	Cutting of taper.
20	G01 Uxx Wxx Fxx	Relief.
21	G00 Zxx	Return.
22	G99 Sxx	Constant surface speed control/cutting speed of finishing.
23	G01 Xxx Fxx	Approach to finishing.
24	G01 Zxx Fxx	To jaw end surface/feed speed of finishing.
25	G01 Xxx Zxx	Chamfering.
26	G01 Xxx Zxx	Cutting of taper.
27		No necking \rightarrow to process 32.
28	G96 Sxx	Constant surface speed control/cutting speed of roughing.
29	G01 Xxx	Necking.
30	G01 Zxx	Necking.
31	G96 Sxx	Constant surface speed control/cutting speed of finishing.
33	G01 Uxx Wxx Fxx	Relief.
33	G01 Xxx	Relief.
34	G01 Zxx	Approach to cutting of end surface.
35	G01 Xxx Fxx	Cutting of end surface/feed speed of finishing.
36	G01 Uxx Wxx Fxx	Relief.
37	G00 Xxx Zxx	Return to the front of jaw end surface.
38	G00 Xxx Zxx	Return to starting point.
39	G22	Stroke limit check 2,3 on.
40	M05	Spindle stop.
41	G97	Constant surface speed cancel.
42	M30	Soft jaw forming end.

(4) Inner 2 stage Jaw

Table 8-9 (d) Operation of simple soft jaw forming function (inner 2 stage jaw)

Process	Command	Description
1	G18	Z-X plane selection.
2	G99 Fxx	Every revolution, feed speed of roughing.
3	G96 Sxx	Constant surface, cutting speed of roughing.
4	G50 Sxx	Spindle rpm clamp, soft jaw forming spindle max. rpm (H_NAMA[34]).
5	M03	Spindle forward rotation.
6	G22	Stroke limit check 2,3 off.
7	G00 Xxx Zxx	Approach to the point immediately before the jaw end surface (Jaw end surface + H_NAMA[31]).
8		When cut-in amount=0, no roughing \rightarrow to process 33.
9		Roughing end position Is reached in the next cut-in \rightarrow to process 23.
10	G01 Xxx Fxx	Deepen the cut-in to X by 1 cut (D)/dry cutting speed.
11		No dry cutting section \rightarrow to process 13.
12	G01 Zxx	Dry cutting
13	G01 Zxx Fxx	Rough cutting/feed speed of roughing.
14		When X current position = D - finishing amount, \rightarrow to process 19.
15		When X current position < D - finishing amount, \rightarrow to process 20.
16		When cutting of 2nd stage taper is finished, \rightarrow to process 20.
17	G01 Xxx	To the height of 2nd stage taper.
18	G01 Zxx	To the starting point of 2nd stage taper.
19	G01 Xxx Zxx	Cutting of 2nd stage taper.
20	G01 Uxx Wxx Fxx	Relief.
21	G00 Zxx	Return.
22		ightarrow to process 9.
23	G01 Xxx Fxx	To the roughing last X position.
24	G01 Zxx Fxx	To jaw end surface/feed speed of roughing.
25	G01 Xxx Zxx	Cutting of taper.
26	G01 Uxx Wxx Fxx	Relief.
27		When cutting of 2nd stage taper is finished, \rightarrow to process 32.
28	G00 Xxx	To the height of 2nd stage taper.
29	G01 Zxx	To the starting point of 2nd stage taper.
30	G01 Xxx Zxx	Cutting of 2nd stage taper.
31	G01 Uxx Wxx Fxx	Relief.
32	G00 Zxx	Return.
33	G96 Sxx	Constant surface speed control/cutting speed of finishing.
34	G01 Xxx Fxx	Approach to finishing.
35	G01 Zxx Fxx	To jaw end surface/feed speed of finishing.
36	G01 Xxx Zxx	Chamfering.
37	G01 Xxx Zxx	Cutting of taper.
38		No necking \rightarrow to process 43.

39	G96 Sxx	Constant surface speed control/cutting speed of roughing.
40	G01 Xxx	Necking.
41	G01 Zxx	Necking.
42	G96 Sxx	Constant surface speed control/cutting speed of finishing.
43	G01 Uxx Wxx Fxx	Relief.
44	G01 Xxx	Relief.
45	G01 Zxx	Approach to end surface cutting.
46	G01 Xxx Fxx	End surface cutting/feed speed of finishing.
47	G01 Uxx Wxx Fxx	Relief.
48	G01 Xxx Fxx	Approach to 2nd stage chamfering.
49	G01 Zxx Fxx	To 2nd stage end surface/feed speed of finishing.
50	G01 Xxx Zxx	2nd stage chamfering.
51	G01 Xxx Zxx	Cutting of 2nd stage taper.
52		No necking \rightarrow to process 57.
53	G96 Sxx	Constant surface speed control/cutting speed of roughing.
54	G01 Xxx	Necking.
55	G01 Zxx	Necking.
56	G96 Sxx	Constant surface speed control/cutting speed of finishing.
57	G01 Uxx Wxx Fxx	Relief.
58	G01 Xxx	Relief.
59	G01 Zxx	Approach to end surface cutting.
60	G01 Xxx Fxx	End surface cutting/feed speed of finishing.
61	G01 Uxx Wxx Fxx	Relief.
62	G00 Xxx Zxx	Return to the front of jaw end surface.
63	G00 Xxx Zxx	Return to the starting point.
64	G22	Stroke limit check 2,3 on.
65	M05	Spindle stop.
66	G97	Constant surface speed control cancel.
67	M30	Soft jaw forming end.

III. II Screen Operation

- 1. Screen Layout and Basic Operation
- 2. Operation of Overall Screen
- 3. Position
- 4. Work Coordinate (Offset)
- 5. Set (Data)
- 6. Macro Variable
- 7. Plot
- 8. Plot Parameters
- 9. Tool (Offset)
- 10. Alarm Diagnosis
- 11. System
- 12. Program
- 13. Program List
- 14. Input/Output
- 15. Test Operation
- 16. Manual Operation
- 17. User Screen
- 18. Q Setter Setting
- 19. Ladder Live Line Display

1. Screen Layout and Basic Operation

One screen fundamentally consists of the following (See Fig. 1-0):

- 1 Main display area
- 2 Machine status display area (including a screen title)
- ③ Program No. display area (No. O, No. N)
- (4) Key input area
- 5 Function menu display area

② Machine status display area	(3) Program number display area		
1 Main display area			
(4) Key input area			
5 Function menu d	lisplay area		

Fig. 1-0 Configuration of basic screen

- In the overall screen, the tool data and command data are summarized.
- On certain screens, windows (small screens) may be overlapped and displayed, when a function menu key is pressed.

(As a rule, if the same key is pressed again, the window disappears.)

• By setting the time to transition to the Good Night screen, the screen can be blanked (darkened) if you do not operate any keys within that time.

1-1 Main Display Area

Although the design differs from one screen to another, the following describes a basic operating method.

 \bigcirc $(\uparrow) / \downarrow$ (Cursor move keys)

Used to move the cursor up/down by one position. When the cursor is located at the top or bottom of the screen, the screen is scrolled by pressing them. The double-spread page such as parameters is not scrolled. They are also used to perform a search.

 \bigcirc \rightarrow / \leftarrow (Cursor move keys)

Used to move the cursor to the right/left by one position.

○ Provide the image of the

Used to change pages when one page is not enough to display all. Here, the cursor refers to the character displayed in reverse video. Normally, it is surrounded by a yellow-frame guide line. The guide line is to indicate data connection; some screens do not have this. When the pages are changed, the cursor is moved to the beginning of the page. In addition, the following key combinations are available for special operations.

Only the screen is scrolled without moving the cursor.

Moves the page and cursor to the beginning of that screen.

Moves the page and cursor to the end of that screen.

 $\bigcirc SHIFT \rightarrow / SHIFT \leftarrow$

Moves the cursor character by character in editing the program. This allows you to edit finely, not word by word.

1-2 Machine Status Display Area

Usually a screen title is displayed here, but once an alarm occurs when the program is running, its number and an abstract message are displayed. As it displays only one line, if several alarms occur at the same time, only the end one is displayed.

If you want to know the detailed information, turn the alarm diagnosis screen.

Besides, following status is also displayed.

- \bigcirc Dry run status.
- \bigcirc Machine lock status.
- \bigcirc Running mode.
- \bigcirc Running status.
- \bigcirc Chuck outer tightening, outer tightening.
- \bigcirc Q setter mode.

1-3 Program Number Display Area

Displayed in this area are the program number and sequence number being currently executed, and multiplicity and repeat frequency at subprogram call time.

Example) $O1000 \rightarrow O2000 \rightarrow O3000$ L = 10 N1234 O3000, N1234 is being executed. O3000 repests another 10 times. O3000 returns to O2000. O2000 returns to O1000.

1-4 Key Input Area

The entered characters are buffered in here once, and then, input.

Example) P: Absolute value = 1.234 (1.234 is entered)

Also, absolute/incremental value programming can be switched over and a number' search can be performed by switching over the mode. To switch over the mode, press the following character keys when nothing has been buffered.

○ P (P: Absolute value =)

Absolute value programming. The entered numerical value is input as it is.

○ I (I: Incremental value =)

Incremental value programming. The entered numerical value is added and input.

O N (N: Number =)

Number search. The cursor is moved to the entered number. However, the cursor key is used for execution (not the INPUT key). In addition, the following functions are provided for input.

Deletes the character one before the cursor in the key input area.

O SHIFT CANSEL

Deletes the entire key input area.

1-5 Function Menu

On each screens, the lower part of the screen is the function menu. This menu differs depending on the screen. For details, refer to descriptions of individual screens.

○ ∧ key

Pressing this key displays maintenance menu.

This menu allows you to select some screens. Generally, the screen with the function keys is called a operation menu and this one a maintenance menu, respectively.

1-6 Tree Chart



Fig. 1-7(a) OVERALL Screen (RUN) TREE CHART





Fig. 1-7(b) OVERALL SCREEN (MAINTENANCE) TREE CHART



(Note) denotes an option

Fig. 1-7(c) OVERALL SCREEN (BACK) TREE CHART

2. Operation of Overall Screen

When the power is turned on or the \supseteq key is pressed, the Overall screen (Fig. 2-0a) is selected. It is very convenient because it displays many data required for operation. The data includes;

 $\, \bigcirc \,$ Program window

Display and edit of the program.

Search of programs.

 \bigcirc Tool window

Tool data (tool number, tool compensation, tool nose R, tool nose width, tool nose point, tool picture)

Spindle data (speed specification/surface speed specification, actual speed)

Feed speed (every minute specification/every rotation specification)

Rotary tool speed

Spindle clamp speed

 \bigcirc Position window

Tool nose position, remaining travel amount, machine coordinate, relative coordinate Pressure data (chuck pressure, tail stock pressure)

○ Drawing window

Pressing AUX. key changes the selection of each window and enables the key entry.



Fig. 2-0(a) Overall Screen

Press AUX. and moves the cursor to the window you want to change. Press MENU SELECT to change the function key. Pressing function keys described below can change the window screen which was made by dividing the overall screen into 4.



Fig. 2-0 (b) Function Menu

2-1 Program Window

This is located at the upper left part of the screen to display and edit the program. MDI input is also done here. However, expanded editing or background editing is not possible. When a program is running, the display color changes as follows.

Already executed block:	Background green, letters black
Executing or to be executed block:	Background yellow, letters black
Pre-read block:	None
Previous block:	Background white, letter black
Block to be executed next or part to be edited:	Background black, letters white.

The conditions for editing the program are given below.

- Write key has been pressed.
- In the edit mode and not in the automatic operation mode.
- For details of program operation, refer to section 12. Program.
- Here, one-fourth of the program screen is displayed.

2-2 Drawing Window

This is located at the upper right part of the screen to draw the tool track of the running program. As this is the contracted form of the drawing screen, the parameters for drawing are the same as the crawing screen.

2-3 Tool Window

2-3-1 Tool Data

This is located at the lower left of the screen to display the tool data for the cutting surface on the turret (number, type, name, compensation, tool nose R, tool nose width, tool nose point, tool picture).

2-3-2 Spindle Data

The spindle command rpm S and actual rpm are displayed.

During constant surface speed control, "Rotation S" is indicated as "Surface Speed V". During the back mode, the data of each sub-spindle are displayed.

2-3-3 Feed Speed

The feed speed F is displayed.

Feeding per minute is indicated as "F per minute" and feeding per rotation is as "Rotation F".
2-3-4 Rotary Tool Speed(Option)

Rotary tool rpm is indicated.

With a rotary tool being fitted, "Tool S" is indicated.

2-3-5 Spindle Clamp Speed

Spindle clamp rpm is displayed. When the spindle clamp rpm indication is valid, "Clamp S" is indicated. While in Back mode, clamp rpm of the sub-spindle is displayed.

2-4 Position Window

2-4-1 Position Data

From 4 coordinates of tool nose, relative, machine and remaining travel amount, a selected coordinate is displayed at the lower right of the screen, which can be selected with a page key. When the relative coordinate is displayed, after pressing the axis name (U, V, W,...), the 0 setting can be done using the INPUT key.

Also, it is possible to enter the value by selecting an axis using the cursor key.

2-4-2 Pressure Data(Option)

The chuck pressure and tail stock pressure are displayed.

2-4-3 Dwell

When executing the dwell, remaining seconds of the dwell are displayed. When it reaches zero, the dwell display disappears.

Items after this are displayed in the window screen which divides the screen into 4.

2-5 Wear Compensation

Wear compensation is displayed in the window screen.



Fig. 2-5 Wear Compensation

2-6 Macro Variables

Macro variable data are displayed in the window screen.

ACRO VAL.	
001	-
002	_
003	
004	
005	
006	
007	
008	
009	•



2-7 Running Status

The running status is displayed in the window screen. Input is done by moving the cursor.

(Example) (Hour/minute/second) = 0 (set to 0)

(Hour/minute/second) = 1 (1:00:00 is entered) (Hour/minute/second) = 1/2 (1:02:00 is entered)

(Hour/minute/second) = 1/2/3 (1:02:03 is entered)

(1) Scheduled ending

Notice of ending is made effective when End Notice on the page is held "valid". The scheduled ending time is equal to the time length from auto operation start to the ending notice. If the operator enters the scheduled ending time for a program, the call light tells when the machining time reaches the scheduled ending time.

(2) Machining time

Time for machining is summed up (time when the start lamp is ON).

(3) Lap T

Lap time among tools is measure. This is automatically set to 0 on tool changing. No measurement is conducted while NC is held in stand-by state.

(4) Work Count

Under the M12 command, NC counts up the number of cutting and the total number of works cut.

OPERATION STATUS	
SET END C	DN 📀 DFF
SET END	0 Hour 100 Min 130 Sec
WORK COUNTER SET	TIME Hour M. S. CYCLE 30 41 36 LAP T 0 00 04
CURRENT 1588 pc. TOTAL 1588 pc.	AMOUNT TIME Hour M. S. OPERATE 147 05 31 RUNNING 51 20 08 CUTTING 2 06 15

Fig. 2-7 Running Status

2-8 Axis Load Display

The axis load is displayed in the window screen.



Fig. 2-8 Axis Load Display

2-9 Command Value

G code command values are displayed in the window screen.

COMMANE			
01	G01	02	
03		06	G18
07	G40	08	G54
09		10	G64
11		12	G602
13	G710	14	G90
15	G95	21	BR I SK
22	CUT2D	29	DIAMON
47	G290	31	G810

CUMMANU			
01	G00	02	G97
03		04	G69
05	G99	06	G21
07	G40	08	
09	G23	10	G80
11		12	G67
13		14	G54
15		16	G18
17		31	G291

Fig. 2-9 (a) Command Value (When G290, S mode) Fig. 2-9 (b) Command Value (When G291, ISO compatible mode)

2-10 Program List

The Program list data are displayed in the window screen.

Program List					
Program	Size(m)	Comment			
0060	3. 1	_			
0911	6.0				
0912	2. 8	(TL01/01 TL06/34)			
1502	0.9	(DELPATH TEST)			
1503	1.3	(DELPATH TEST)			
1504	0.4				
1505	0.6	(NOSE-COMP-OFF TE)			
1500	0 4				
Ava. 703m/1000m(29/100)Sel. 0/71					

Fig. 2-10 Program List

2-11 G Code M Code

The list of G code and M code is displayed in the window screen. M code and MM code are changed by the function key.

GCode	[F:¥0EM¥STAF¥G_STD_UK.TXT]
Code	Contents 🔺
G000	POSITIONING
G001	LINEAR INTERPOLATION
G002	CIRCULAR INTERPOLATION/HELICAL INTERPOL
G003	CIRCULAR INTERPOLATION/HELICAL INTERPOL
G004	DWELL
G007	VIRTUAL AXIS INTERPOLATION
G009	EXACT STOP
G010	DATA SETTING
G011	DATA SETTING MODE CANCEL
GQ17	Xn-Yn PIANR
G	

Fig. 2-11 (a) G Code

MCode	[F:¥0EM¥STAF¥M_NX_UK.TXT]
Code	Contents 🔺
M000	PROGRAM STOP
M001	OPTIONAL STOP
M002	PROGRAM END
M003	SPINDLE ROTATE CW
M004	SPINDLE ROTATE CCW
M005	SPINDLE & MIL SPINDLE STOP
M008	COOLANT ON
M009	COOLANT OFF
M012	WORK COUNT
MQ13	МТІ СРТИПІЕ ВОТАТЕ СМ. (ОР) 🚬
◀	

Fig. 2-11 (b) M Code

MMCode		[F:¥0EM¥STAF¥A_NX_UK.TXT]
Code	Contents	
<u> </u>		
<u> </u>		
L		
•		

Fig. 2-11 (c) MM Code

2-12 Diagnose

The diagnose is displayed in the window screen. You can display and change DB signals of PC/NC, etc.

ADDRESS	STATUS	Hex
DB90. DBB6	0000-0000	00
DB21. DBB117	0000-0001	01
DB21. DBB118	0000-0000	00
DB21. DBB119	0000-0000	00
DB21. DBB120	0000-0000	00
DB21. DBB121	0000-0010	02
DB21. DBB124	0000-0000	00
DB21. DBB125	0000-0000	00

Fig. 2-12 Diagnose

2-13 Return to Standard Screen

Pressing F0/DEFAULT restores the standard screen of the program, drawing, position and tool.

2-14 Spare Tool (Option)

Spare tools are displayed in the window screen.

3. Position

If you press the F1/POSITION key, the position screen (Fig. 3-0) will be displayed. Items related to position are displayed and these items can be re-written when this screen is displayed.

- Display of nose position, remaining shift amount, relative coordinate system, and machine coordinate system
- Rewriting of relative coordinate system
- \bigcirc Display of tool data
- \bigcirc Display of spindle data
- \bigcirc Display of feed rate

POSITION						00002
JOG RESET	DryRun	M Lock	Chuck IN			N0000
ABSOLUTE			ABSOLU	ле	DIST TO C	60
v	50	0 06	o ×	589.069	x	0.000
~	- 00	9.00	9 z	833. 847	Z	0.000
7	0.0	0 04	7			
L	- 83	3.84	/			
			-			
			RELATI	IVE	MACHINE	
			U	189.069	X 1	89.069
				535. 747	Z S	535. 747
T				<u></u>		
100110700				state		
0FST X	0.000	NOSE R	0.400	TurnS		D[min ⁻¹]
Z	0.000	₩ID. H	5.000	RealS		D[min ⁻¹]
		POINT T	3	min. F		0[mm]
P:ABS. U=						
ARS. INC.	SET UP	OMMAND	ZER	O SET	1	
REAL WRITE /1 WRITE	/2 /3	/4 /5	/6	17 1	8 /9	/0 🗖

Fig. 3-0 Position Screen

3-1 Reloading of Relative Coordinate System

Among the 4 coordinate systems, only the relative coordinate system is reloadable.

For 0 setting, first push F7/ZERO SET to change over the function.

When the function for the axis for zero setting being pushed, the value of the axis gets 0.

To zero-set all axes, push F9/All Ax. ZERO.

To end zero setting, push F7/EXIT.

To input numerals, push the key for the address to be input an display the input area.

Input, then, numerals and push INPUT. Absolute value/increment value input is available.

- EX P: absolute value U = 1.234 INPUT (1.234 is placed in U)
 - I : increment value W = 10.0 $\boxed{\text{INPUT}}$ (10.0 is added and placed in W)

3-2 Command Value Display

Pressing the F4/COMMAND displays the data specified by the program or MDI operation (Fig. 3-2).

POSITION							009
NUTO P	RESET DI	ryRun I	ILack C	huck IN			RCO
COMMAND				ABSOL	UTE	DIST 1	0 60
01 600	02 697	03	S 731	х	490. 586	х	0.000
04 669	05 699	06 621	T0100	Z	244.857	Z	0.000
07 G40	08	09 G23	M	ZB	0.000	ZB	0.000
10 680	11	12 667		C1	335.546	C1	0.000
16 010	14 034	10		0.2	0.000	02	0,000
10 010	20.050.2	21 613	1	62	0.000	44	0.000
22	20 030.2	24 013.					
25	26	27					
28	29	30		RELAT	IVE	-MACHIN	IE
31 6291	32	33		U	90.586	x	90.586
34	35	36		, i i	44 857	ź	44 857
37	38	39		WR	0.000	78	0.000
40	41	42		C1 C	230 403	C1	230,403
4J 46	44	40		0.0	238. 403	00	238. 403
40	50	51		021	0.000	62	0.000
52	53	54					
55	56				State		
0FST X	0.00	0 NC	DSE R	0.312	TurnS		731 [a.is ⁻¹]
Z	10.00	0 10	D. H	0.000	Real S		731 [a.in ⁻¹]
		P	UNT T	3	nin E		Ofeel
ABS. U=		_					
ABS.	INC. SET U	P COMMOD	RESTART	225	132 0		
AN PRITE /1	INTE 72	73	/4 /5	76	11 1		/9 /0 0

Fig. 3-2 Command Value Display

3-3 Set up

Pressing F3/SETUP allows you to input the data on the Setup side. (Fig. 3-3) Use the cursor keys \uparrow and \downarrow to select the spindle speed and turret indexing, and input the data. You cannot input multiple data at one time. To execute the input data, select the MDI mode, input the data, and press INPUT. You will be inquired, "OK ? Y-YES N-NO." Pressing Y executes the input data. Pressing F3/SETUP returns the cursor to the Position side.



Fig. 3-3 Set up

4. Work Coordinates (Offset)

Pressing the F4/WORK OFFSET key displays the Work Coordinates screen (Fig. 4-0). This screen operation is used to shift the machining origin.

NORK OFFSET	DryRun	M Lock	Chuck IN	1		00912 N0000
XUTO RESET	400. 300. 0. 0.	000 000 000 000 000	Chuck IN	POSITIO AL X Z ZB C1 C2	BSOLUTE 490. 586 244. 857 0. 000 321. 675 0. 000	N0000
	90.	000		X Z ZB C1 C2	ACHINE 90.586 44.857 0.000 321.675 0.000	
COORD. P (00) /1 /2	ABS. NRITE /3 WRIT	2ND.REF.F E /4 /5	JAH /6	11	/8 /9	

Fig. 4-0 Work Coordinates (Machining Reference Point Shift)

As described in the instruction manual (PROGRAMMING), Section 7-2 "Tool Nose Coordinate System", the position of the tool nose serves as the reference position of the coordinate system. Shifting of the machining origin, there are three methods – machining reference point shift, machining allowance, and work length.

Pressing the function key changes the input mode as follows.

Each function key and the key input area are as follows.

Function key	<key area="" display="" input=""></key>
F1/COORD. P	ightarrow "Removal amount (P) Z ="
F3/ABS. WRITE	\rightarrow "P: Absolute value Z ="
F4/INC. WRITE	\rightarrow !I: Incremental value Z ="

4-1 Removal Amount

Machining allowance = Length from the chuck jaw face to work end face – work length. First cut the work end face within the limits of cutting allowance, so that the black layer on the end face is removed and escape in the same condition in the direction of the positive X axis. (Do not move the Z axis.)

Next, stop the rotation of the spindle. Measure the overall length of the work and find the cutting allowance. Enter this measured value as the machining allowance.

(If the cut is excessive, the value becomes negative.)

4-2 Machining Reference Point Shift

The machining reference point is located at a length between the end faces of the chuck jaws (work shift amount) from the machine zero point. Press F3/ABS. WRITE or F4/INC. WRITE to display "P:ABSOL. VALUE Z=" in the key input area, and press the curs or key \uparrow or \downarrow to adjust the cursor to the axis you want to change. Then, input a machining reference point shift amount. An X-axis shift amount cannot be changed.

4-3 Work Length

The work length is the length between the end face of the chuck jaw and the machining zero point. Press F3/ABS. WRITE (or F4/INC. WRITE) to display "P: ABSOL. VALUE Z =" in the key input area, and press the cursor key \uparrow or \downarrow to adjust the cursor to Work Length. Then, input the work length.

4-4 Setting of 2nd Reference Point

With $\boxed{F5/2ND \text{ REF. P}}$ pushed, 2nd Reference Point Set page (Fig. 4-1) appears. Use this page to set X and Z axes of the 2nd reference point (G30). When the machine X/Z axes have been positioned to the 2nd reference point and with $\boxed{F2/ENTER}$ having been pushed, "Is this OK? Y-Yes, N-No" appears for confirmation. For OK, push \boxed{Y} key.

With F5/EXIT	$\lceil $, the original page is recov	/ered.
--------------	---	--------

NORK OFFSET AUTO RESET DryRun TORK SHIFT 2ND. REF. PNT (630) SET	V Lock	Chuck IN DOCITION	0091 N000
	2ND. REF. P	Z	
	X Z	200. 000 200. 000	MACHINE X 90.586 Z 44.857 ZB 0.000 C1 54.218 C2 0.000
COORD . P Z=	/4 EXIT /5	JAW /6 /7	/0 /9 /0

Fig. 4-4 2nd Reference Point

5. Set (Data)

If you press the F5/SETTING key, the setting (data) screen (see Fig. 5-0) is displayed. There are four types of the screen.

A:PROGRAM B:CANNED CYCLE C:STROKE D:ECO eco

To flip each tab, select from $A \sim D$ on the keyboard.

5-1 PROGRAM

				00912
06	RESET DryRun Lock (huck IN		NOOOG
A:PROG	RAM B:CANNED CYCLE C:STROKE D:Eco eco			
A-01	Single block stop in all macro		@ Invid (Valid
A-02	Single block stop in block made i matic tip of the blade R correcti	nternally for auto on	Cinvid 6	Valid
A-03	Editing of program 08000-09999		C Invid 6	Valid
A-04	Display of program 08000-09999		Cinvid 6	Valid
A-05	Rewriting of parameter		Cinvid 9	Valid
	7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	COGRAM	/8 /9	/0

5-2 CANNED CYCLE



Fig. 5-2 CANNED CYCLE

5-3 STROKE

ETTING OS	RESE		DryRun	CREWER 1	ock	Chuck			1	- 1	009 NOO
C-01	X-Axis	coord	value	(limit	2,+>	co				9999	999
C-02	Y-Axis	coord	value	(limit	2, +>					9999.	999
C-03	Z-Axis	coord	value	(limit	2,+>					9999.	999
0-04	X-Axis	coord	value	(limit	2, ->					-9999	. 999
0-05	Y-Axis	coord	value	(limit	2, ->					-9999	. 999
0-06	Z-Axis	coord	value	(limit	2, ->					-9999	. 999
C-07	X-Axis	coord	value	(limit	3, +>					9999.	999
C-08	Y-Axis	coord	value	(limit	3, +>					9999.	999
0-09	Z-Axis	coord	value	(limit	3, +)					9999	999
0-10	X-Axis	coord	value	(limit	3, -)					-9999	. 999
0-11	Y−A×is	coord	value	(limit	3, ->					-9999	. 999
0-12	Z-Axis	coord	value	(limit	3, ->					-99999	9.000
P:AB	is = [,				
	21	12	13	74	/6	CHUCK SET	76 STOCK	19	/8	19	/0 (c

Fig. 5-3 STROKE

5-4 ECO eco



Fig. 5-4 ECO eco

5-5 Chuck Setting(Option)

Pressing F6/CHUCK SET displays the chuck setting screen (Fig. 5.5), where you can set and display the chuck pressure.



Fig. 5-5 Chuck Setting

5-6 Tail Stock Setting(Option)

Pressing F7/TAIL STOCK SET displays the tail stock setting screen (Fig. 5.6) where you can set and display various tail stocks.



Fig. 5-6 Tail Stock Setting

6. Macro Variable

Press F8/MACRO VAL. in the PROGRAM screen F2/PROGRAM. The MACRO VARIABLE screen appears (Fig. 6-0 (a)). The cursor is moved by cursor keys \uparrow \downarrow \rightarrow \leftarrow or page keys B B.

6-1 Macro Variable and Data Display

The macro variable data is classified into the following:

- 1-33 Local variables (correspond to call multiplicity)
- 100-199 Common variables (turned to "null" at power-off time)
- 500-999 Common variables (with name, remembered if the power is turned off)

The number of significant digits of data is 8 (\pm 999999999 to \pm 0.0000001). When the numerical value exceeding this limit has been input, the message "OVER FLOW" is output. Nothing is displayed in case of the "null" data (empty, not 0). The name can be input up to 12 characters, but it is given to the common variables 500-599.

(1) Data deletion

F7/DATA CLEAR appears. Pressing this menu displays the question at the center of the screen whether to erase with 0 or "null". Select either of them with the cursor key (\uparrow or \downarrow) and press the INPUT key. Finally, the message "OK?" appears in the key input area for safety confirmation. Press the Y key.

(2) "Null" input

If you press the CANSEL key when the key input area contains nothing, the "null" characters are displayed. Then, pressing the INPUT key turns the data at the cursor position to "null".

(3) Deleting the name

Set the cursor to the name you want to delete (common variable 500-599), press SPACE, followed by INPUT.

WACRO	Lucas	1	1.000			00912
306	RESET	DryRun	I LOCK	Chuck IN		80000
1.000	AL VALUE			LOCAL VALUE		
	NO D	DATA		NO	DATA	
	1			16		
	2			17		
	3			18		
	4			19		
	5			20		
	6			21		
	7			22		
	8			23		
	9			24		
	10			25		
	11			26		
	12			27		
	1.4			28		
	15			20		
	13					
P:A	BS =			-		
	OLUT INCRIME	/3	/4 //	5 /6 DATA	/7 TX	/8 /0 2
			-) M	Verieble (Le		

Fig. 6-0 (a) Macro Variable (Local Variable)

TAGRO		_				00912
JOG	RESET	DryRun	W Lock	Chuck IN		N0000
CON	ION VALUE			COHON VALUE		
	NO	DATA		NO	DATA	
	100			115		
	101			116		
	102			117		
	103			118		
	104			119		
	105			120		
	106			121		
	107			122		
	108			123		
	109			124		
	110			125		
	111			126		
	112			127		
	113			128		
	114			129		
P :	ABS =				(mum 1)	
	SOLUT INCRIME /1 NT /2	/3	/4 /	5 76 CLEAR	EXIT 1 /7 /8	/9 /0

Fig. 6-0 (b) Macro Variable (Common Variable)

NO	DATA	NAME	
500	200. 0000000		
501	100.0000000		
502	1.0000000		
503	1.0000000		
504			
505			
506			
507			
508			
509			
510			
511	11.0000000		
512	12.0000000		
513			
514			

Fig. 6-0 (c) Macro Variable (Common Variable with name)

6-2 Number Search

The page and cursor can be moved at one time by searching the macro variable No. A search can be performed by pressing the cursor key (\uparrow \downarrow \rightarrow \leftarrow) after inputting \mathbb{N} and a subsequent numerical value.

Example) N: No. = $12 \downarrow$ (Moves to No. 12)

7. Plot

Pressing the F7/GRAPHIC key displays the Graphic screen (PREVIEW EXIT) (Fig. 7-0) This screen plots the tool path and also displays the following data for reference to plotting.

- \bigcirc Parameter plotting plane
- \bigcirc Tool nose position
- \bigcirc Spindle speed S, feed rate F, tool command T
- O Machining time, cutting time
- O Program list in execution

A locus is drawn in the values of the work coordinate system. As too many lines can confuse movement, the tip is expressed in a small dot. To erase the graphic page, push ORIGIN.

GRAPHIC							00912
JOG	RESET	DryRun	M Lock	Chuck IN			NOODO
						ABSOLUT X Z ZB C1 C2	2 490. 586 244. 857 0. 000 72. 075 0. 000
PROGRAM ; 00912						Turn MIN. Tool	731[nin ^{**}] 0[nn] 0100
(TL01 / 8 TL11 , N01 G50	01 TL06 /32 /100 TL12 / \$5000 J	2 TL09 /19 /104 W90.0	TL10 /52 TL D150.0 H2.(.07 /112 T)L0)]	108 /11	CYCLE CUTTING SCALE	103:37:03 8:39:51 10
			SCM F	28	RO SET	PREVIEW	
ELLE PARAM	/1 /2	/3	/4 0N/0FF /5	/6	17	/8 /9	/0 []

Fig. 7-0 Graphic Screen (PREVIEW EXIT)

The following setting are allowed for plotting. For details, refer to the next section.

- Selection of plotting plane
- Specification of angle or rotation (horizontal, vertical)
- O Plotting range (maximum, minimum)
- \bigcirc Scale width indication
- \bigcirc Specification of plots per tool (color specification)
- \bigcirc Selection of cutting feed line
- \bigcirc Selection of rapid traverse line
- \bigcirc Color assignment for drawing point

8. Pre-machining Plotting

Pressing the F9/PREVIEW menu of the F7/GRAPHIC key displays the function key for premachining plotting.(Fig. 8-0)

Next, push F3/PREVIEW START key to start pre-machining plotting.

- Note 1) In order to start pre-machining plotting, first perform zero point return initialize other states of Machine such as mechanical clamp.
- Note 2) When Locus image is obscure in display, lower speed with the feed speed switch.
- Note 3) Any function whose conditions change by machine operation (macro program using skip function) cannot be executed in pre-machining plotting.

GRAPHIC							01575
EDIT	RESET	DryRun	M Lock	Chuck OUT			N0000
						ABSOLUT X C	2 300. 000 500. 000 0. 000
						Turn	-1 - 713
FROGRAM						N N	Olmin'J Olmol
01575 <	INPOS TEST)				-	Tool	1000
G990 CC	_HS_PROC_SE	ET_LOGMODE (0,35)]			-	201-10-00
G990 G8						CUTTING	172:01:25
19990 00	L 20				·	SCALE	10
DATA >							
CONTRACTOR) /1 /2 \$	REVIEW TART /3	/4 SCALE IN/OFF /5	/6 ZERO SE	ET /7 /	9 PREVIEW	/0 🕞

Fig.8-0 Pre-machining Plotting Screen

9. Plotting Parameters

With the F1/GRAPHIC PARAM menu of the F7/GRAPHIC, the plotting Parameter screen (FIg. 9-0(a) or Fig. 9-0(b)) appears over the Plot screen.

This screen allows you to set the plotting parameters.

Pressing the F2/RANGE key displays the Range Set screen (FIg. 9-0(a)) and pressing the F3/PLANE key displays the Plant Set screen (Fig. 9-0(b)).



Fig.9-0(a) Plotting Parameter (Range Set)

Tat. PLANE Int. PLANE Int. PLANE PLANE ANGLE HOL	1 PI IL ANGL R AXIS	PLANE -1 LANE -1 LE HOL VER
AXIS 1	1 Z AXIS	
	2 X 3	S 1 2 3
Graphic plane1	0 1 2	3 4
(NONE)	ً ↓ 1 ,ً	

Fig.9-0(b) Plotting Parameter (Plans Set)

\bigcirc Setting plotting parameters

First move the frame cursor to the column of the parameter to be set using the cursor key $|\uparrow\rangle$ $|\lor\rangle$.

At that time, a simple explanation is displayed in the explanation column.

Range set

(1) Plotting Range

Set the maximum and minimum plotting values of each axis. The center coordinate (middle of the maximum and minimum values) and magnification factor (at which the maximum and minimum values stay within the screen) for plotting are decided. Input tje coodinate value (work coordinate) in the key input area and press the INPUT key to decide. The maximum value and the minimum value can be set at left or right at that time.

(2) Scale

A Scale width is set here.

(3) Plot Per Tool

Every time the tool is changed, a plotting color is changed. However, this is ineffective when plotting the specified tool. Up to 6 colors are available. After the 6th color, it returns to the first one. Make setting at "Feed Line Color"

The set one is marked with \bullet . To after, select with the cursor key (\rightarrow or \leftarrow) and press the INPUT key to decide.

(4) Cutting Feed Line

Specify a type of cutting feed line. The set one is marked with \bullet . To alter, select with the cursor key (\rightarrow or \leftarrow) and press the INPUT key to decide.

(5) Rapid Traverse Line

Specify a type of rapid traverse lines. The set one is marked with \bullet . To alter, select with the cursor key and press the INPUT key to decide.

(6) Feed Line Color

When Plot per Tool is effective, set the changed-to color. To make setting, select color designation with the cursor key. Then, specify the tool with the cursor key.

In accordance with the description , set numerical value 0-7 and press the **INPUT** key to determine.

(7) Plotting Point Color

Specify a color of plotting point.

To make setting, select color designation with the cursor key.

In accordance with the description, set a numerical value 0-7 and press the **INPUT** key to determine.

Plane Set

(1) Plotting Plane

Specify the plotting plane. You can select out of the following 6 types.



Fig. 9-0 (c) Plotting Plane

In accordance with the description, set a numerical value 0-4 and press the INPUT key to determine. The selected plane is displayed. The plane setted a numerical value -1 is not displayed.

Note) No scale is displayed when the plotting plane is equal to 0 (in 3-axes display)

(2) Rotation Angle

This is effective only when the plotting plane is 0 (3 axes display).

Input the angel in the key input area and press the **INPUT** key to decide.

(a) Horizontal rotation angle

Specify the horizontal plane rotation angle within a range of ± 180 in an increment of 1°

Example) When the plotting plane is (XYZ) and the vertical rotation angle is 90°



Fig. 8-0 (d) Ratation Angle

(b) Vertical rotation angle
 Adjust the slope angle of the vertical axis.

Example) When the plotting plane is (XYZ) and the horizontal rotation angle is 0°



Fig. 9-0 (e) Vertical Rotation Angle

(3) Specified axis

Set the axis name which you want to specify. Minus ("-") can be added to it.

10. Tool (offset)

Pressing the F3/TOOL key displays the Tool screen (Fig. 9-0).

The compensation data for each tool number is displayed and set as shown below.

	Tool Size	Tool Nose Radius	Tool Nose Point	Tool width
Form	XYZ	R	Т	Н
Wear	UVW	Q		J

Table 9-0 Tool Form / Wear

In addition, the following functions are provided.

- \odot $\,$ Display of the tool nose position and machine coordinate system
- O Data deletion
- \bigcirc Setting of the tool nose shape.



Fig. 10-0 Tool (offset) Screen

Using tool compensation data

Tool compensation data is divided into form and wear data for each item.

Compensation using T in the program corresponds to the tool number of the tool (compensation) screen. For details refer to the section on Tool Function (T function) in Program Editing.

10-1 Setting of Offset Value

Offset values are classified into geometry and wear. To make setting, adjust the cursor and set through the key input area. The wear can be input any time, but to input the geometry, the manual mode must be selected and the write switch must be enabled.

When the geometry is input, the wear will become 0.

 \bigcirc Data input method

The geometry is input as an absolute value and the wear is input as an increment value using $\boxed{\text{INPUT}}$ key.

 \bigcirc Wear input clamp

Values greater than the value set in the parameter (MD62200[1]) cannot be input. The message "Clamped value is exceeded" appears.

Note) If the wear is input during automatic operation, the wear data of the relevant tool will be reflected from the next T-command onward, because the coordinate system will not be set. (The coordinate system will be set in the manual mode.)

10-2 Tool Selection

10-2-1 Name Setting

To set the tool, usually the tool name is set. Type, tool nose shape and too name are simultaneously set. To set the name, use the function menu. First press $\boxed{F3/NAME}$, which opens a window at the center of the screen (Fig. 9.1). Use cursor key $\boxed{\uparrow}$ $\boxed{\downarrow}$ or page key $\textcircled{\textcircled{B}}$ $\textcircled{\textcircled{B}}$ to select and press \boxed{INPUT} to determine.

NAME
ROUGH I.D.
OD FORM
FACE FORM
FINISH OD
FNSH FACE
GRV. EXT.
G. EXT. FACE
G. INT. FACE
NECKINK OD NECKING ID
EXT. THREAD
INT. THREAD
TURN

Fig. 10-2-1 Tool Name

If you want to attach dimensions before the tool name, first determine the position of the tool name using the cursor, then enter the alphanumeric data and determine them by pressing INPUT.

The name is up to 12 characters. Input more than this is omitted.

10-2-2 Setting of Type

In case of special a special tool, set the type and picture of the tool.

Pressing F2/TYPE can change the tool type already selected. When a window appears at the center of the screen (Fig. 9-2-2), use the cursor key \uparrow \downarrow to select and press INPUT to determine.



Fig. 10-2-2 Type

10-2-3 Setting of Tool Nose Shape

Pressing F4/TIP FORM can change the tool nose shape already selected.

When a window appears at the center of the screen (Fig. 9-2-3), use the cursor key \uparrow \downarrow \downarrow \rightarrow \leftarrow to select and press INPUT to determine.



Fig. 10-2-3 Tool Nose Shape

10-3 Data Clear

This function is used when you want to start from the beginning, for example, to delete a line of the tool data indicated by a cursor or to make some data 0 altogether for all tools.

Pressing $\boxed{F7/DATE CLEAR}$ opens a window at the center of the screen showing the data you can clear. Use the cursor key $\boxed{\uparrow}$ \downarrow to select any and press \boxed{INPUT} to determine. You are asked "Is it OK? Y-Yes, N-No". Press \boxed{Y} if it is OK with you.

DATA	CLEAR	
ONE TOOL GEOMETRY WEAR (ALL NAME (ALL ALL DATA	CLEAR (ALL TOOL) TOOL) TOOL)	

Fig. 10-3 Data Clear

10-4 Number Search

You can move the page and cursor at once by searching the tool number. Press [N] and enter the following number, then press the cursor key $[\uparrow]$ $[\downarrow]$ $[\rightarrow]$ $[\leftarrow]$ to

exe	eci	ite.	

Example: N: Number = 12	\downarrow	(Move to No.12)
-------------------------	--------------	-----------------

11. Alarm Diagnosis

Press the A key, and then, F3/ALARM DIAG key maintenance menu. The Alarm Diagnosis screen (Fig. 10-0) appears.

All the generated alarms are displayed, sorted into the CNC alarms and the PLC alarms (issued by ladder sequence software of the machine).

When one screen is not enough to display all the alarms, they will be extended over multiple pages. Use the page key or to change over the screen.

[3000] : Emergency stop EDIT RESET DryRun W Lock Chuck OUT	00912 N0000
3000 [[ONO]] : Emergency stop 2001/05/23 17:46] 1
700044 [[PLC]] : EMG-STOP pressed, DB2.DBX185.4, user OM 2001/05/23 [17:46]]
	•
LATOUT (33) /1 /2 /3 /4 /5 Hist /6 /7 /8 /9	/0

Fig. 11-0 Alarm Diagnosis Screen

11-1 Alarm History

Press F6/ALARM HIST in the ALARM DIAGNOSE screen. The ALARM HISTORY screen appears (Fig. 11-1). It lists the occurrence date and time, type, and description of each alarm in order of more recent ones. The screen can store up to 150 CNC and PLC alarms.

JOG RESET DryRun II Lock Chuck IN	00912 N0000
700032 [PLC] POWER ON requested !!DB2.DBX184.0 2001/05/21 13:47] =
700032 [PL0] : POWER ON requested !!DB2.DBX184.0 2001/05/21 [13:47]	
[700032] [[PL0]] : POWER ON requested !!DB2.DBX184.0 [2001/05/21][13:47]	
700032 [PLC] : POWER ON requested !! DB2. DBX184.0 2001/05/21 13:47	
700032 [PLC] : POWER ON requested !! ·····DB2.DBX184.0 2001/05/21 13:47].
All Alar CNC HI PLC / ALARM CLR // //8 //9	/0

Fig. 11-1 Alarm History

12. System

Press the \land key, and then, F4/SYSTEM the maintenance menu. The System screen (Fig. 11-0) appears. This is a collection of the screens used for maintenance by the maker. The collection of screens used for maintenance on the manufacture's side include the following:

O Parameter

- TIME & DATELAN/UUP
- Assembly AdjustmentSoftware Version
- O ParaShot 2000
- LSSOL InformationSTAF Setting

0

O Y menu

A menu is displayed on the screen. An item in reverse video indicates that it is being selected. To select a menu item, input an item number directly with the keys or select it with the cursor move keys, \uparrow , \downarrow keys. Then, press INPUT to change over the screen to the selected one.

	MENU	
1. PARAMETERS	16.	
2.	17.	
3. MAINTENANCE PARAMETERS	18.	
4.	19.	
5.	20.	
6.	21.	
7. SOFTWARE VERSION	22. TIME _DATE	
8.	23. LAN / UUP	
9.	24. LANGUAGE	
10.	25.	
11.	26.	
12.	27. STAF SETTING	
13.	28.	
14.	29.	
15.ParaShot 2001	30. Y MENU	
untra -		

Fig. 12-0 System Screen

12-1 Parameter

Set the cursor to "Parameter" on the System screen and press the INPUT key. The Parameters screen appears.

Display and set the NC parameters.

PARAMETER	5											00912
JOG	RESET	DryRun 1	Lock	Chuck IN								N0000
						_					~	
	7 6 5 4	3210	Hex		<u>~</u>	b	5	4 3	2	1	0	Hex
8000	0000	-0000	_00_	8020	0	0	0	0 - 0	0	1	0	02
8001	0 0 1 0	-1101	2D	8021	0	0	0	0 - 0	0	0	0	00
8002	0 0 0 0	-0000	00	8022	0	0	0	0 - 0	0	0	0	00
8003	1001	-0100	94	8023	0	0	0	0 - 0	0	0	0	00
8004	0 0 0 0	-0010	02	8024	0	0	0	0 - 0	0	0	0	00
8005	0000	-0000	00	8025	0	0	0	0 - 0	0	0	0	00
8006	0000	-0110	06	8026	0	0	0	0 - 0	0	0	0	00
8007	0 0 0 0	-0011	03	8027	0	0	0	0 - 0	0	0	0	00
8008	0 0 0 0	-0001	01	8028	0	0	0	0 - 0	0	0	0	00
8009	0 0 0 0	-0000	00	8029	0	0	0	0 - 0	0	0	0	00
8010	0000	-0000	00	9000	0	0	0	0 - 0	0	1	0	02
8011	0000	-0100	04	9001	0	0	0	0 - 0	0	0	0	00
8012	0000	-0000	00	9002	0	0	0	0 - 0	0	0	0	00
8013	0 0 0 0	-0000	00	9003	0	0	0	0 - 0	0	0	0	00
8014	0 0 0 0	-0000	00	9004	0	0	0	0 - 0	0	0	1	01
8015	0000	-0000	00	9005	0	0	0	0 - 0	0	0	0	00
8016	0000	-0000	00	9006	0	0	0	0 - 0	0	0	0	00
8017	0000	-0000	00	9007	0	0	0	0 - 0	0	0	0	00
8018	0000	-0000	00	9008	0	0	0	0 - 0	0	0	0	00
8019	0000	-0000	00	9009	0	0	0	0 - 0	0	0	0	00
P:ABS.												
PC Para	e Int /1 Paras /2 P	eal aram /3 Param /	General /4 MD /6	Channel Ax MD /6	is MO	/7		/8		15		/0

Fig. 12-1 Parameter

12-2 Assembly Adjustment

Set the cursor to "Assembly Adjustment" on System screen and push INPUT . Assembly Adjustment screen appears.

Soft limit and Zero point setting are displayed and set.

Machine Adjust				00912
JOG RESET	DryRun 🖬	Lock Chuck	IN	NOOOO
Reference Set	KACHTNE X 0.00 Z 0.00	100 0 % 100 0 %		
Soft Stroke Strake Limit * Direction - Dir X 12345,678 -123 Z 34567,000 -345	1 Str. ection * Directi 45.678 23456. 67.000 45678.	oke limit 2 ion - Direction 789 -23456.000 000 -45678.000	York Limit + Direction - Dir 100000,123 -12345 234567,000 -2345	ectica 56.000 67.000
				CLAMP
P:ABS.= Soft Linit /1 /2	/3 /4	/s SET	int /6 /7	/8 /9 /0

Fig. 12-2 Assembly Adjustment Screen

As for details of the zero point, see "5.2 How to set zero point of absolute encoder" of the Maintenance Edition.

12-3 ParaShot2000

Set the cursor to "Parashot 2000" on System screen and push INPUT. Parashot 2000 screen appears.

ParaShot 2000 00912 406 RESET DryRup Wilcock Chuck IN N0000								
1. Please remove write-protection if card type is SRAM-TYPE(No ATA-TYPE).								
2. Please insert the card to the side-slot of the panel.								
3. An automatic setting is executed pushing the F1[AUTOSET START] key.								
The card data erased after auto-setting. (The caravan data remains)								
(CAUTION: Past ParaShot V1.0"1.1 data cannot be used.)								
AUTOSET START /1 /2 /3 /4 /5 /6 /7 /8 /9 /0								

Fig. 12-3 ParaShot2000 Screen

12-4 Software Version

Set the cursor to "Software Version" on System screen and push INPUT .

Software Version screen appears.

Software Versions are displayed.

SOFTWARE VERSION										00912
JOG	RESET	DryR	un	Lock	Ch	uck IN				N0000
Function	Name		Softw	are Versio	on	Functio	n			
SYSTEM				01.00.0	09	CNC sys	tem			
NC				00.06.0	01	NC soft	oware			
				01.00.0	00					
HI				01.05.0	07	HI soft	oware			
PMC				denso1_(00	Ladder	program			
MULTI				L-V9R1. (00	MULTI				
Machine	Number			EART	TH	Machine	Number			
MMC103	06.01.08.2	001/03/	19							
WINDOWS VE MS-DOS VER Matchine.exe param.exe 'dpdh.exe 'dp.exe 'dp.exe 'b.exe 'h32.exe 'w.exe W.exe W.exe W.EDITOR.EX	RSION: 4.0 SIDN: 5.101 06.01.08 20 06.01.08 20 06.01.08 200 06.01.08 2001 06.01.08 2001 06.01.08 2001 06.01.08 2001 06.01.08 2001 06.01.08 2001	 2001/03/0 01/03/0 1/03/07 1/03/07 /03/07 1/03/07 1/03/07 3 2001/0	A07 06.01 7 06.01 7 06.01 06.01 06.01 06.01 7 06.01 06.01 06.01 06.01	1 *						
No. 1	HNI 1 DETAIL /2	13		/4 /5		/6	17	78	79	/0

Fig. 12-4 Software Version
12-5 Date and Time

Set the cursor to "Date and Time" on System screen and push \fboxtimescreen and Time screen appears.

Setting at date JOG RESET	DryRun 🖬 Le	ock Chuck IN		00912 M0000
Date		Ti	ne	
Lay <u>Sun Mon Tue W</u> 29 30 1 6 7 8 13 14 15 1 20 21 22 27 28 29 3 3 4 5	2001 ed Thu Fri Sat 2 3 4 5 9 10 11 12 16 17 18 19 23 24 25 26 30 31 1 2 6 7 8 9			
NC Date	2001/5/22	NC	Time 1	0:57:12
GUIDE				
Please input the C Please delimit by	hristian era by four '/' . Example 2000/1	digits. 1/27		
Date Time /2	/3 /4	/5 /6	/7 /8	/9 /0

Fig. 12-5 Date and Time Setting

12-6 LAN/UUP

Set the cursor to "LAN/UUP" on System screen and push INPUT.

LAN/UUP screen appears.

IP Adress, Default Gateway and User Setting are displayed and set.



Fig. 12-6 LAN/UUP

12-7 LANGUAGE

Set the corsor to "LANGUAGE" on System screen and push INPUT .

LANGUAGE screen appears.

You can set the language to be displayed on the screen. After setting, when the power is turned on again, the language changes as you specified.

LANGUAGE		01575
EDIT RESET DryRun Malack	Ghuek OUT	NOODO
Now selected Language	ENGLISH	_
Next Power on Language	ENGLISH	
If change Language then Please Power off		
UAPAN ENGLISH DERMAN // /// /// /////////////////////////		/9 /0

Fig. 12-7 LANGUAGE

12-8 LSSOL Infomation

Set the cursor to "Lssol Information" on System screen and push INPUT. Lossl Information screen apears.



Fig. 12-8 LANGUAGE

12-9 STAF Setting

Bring the cursor onto the "STAF Setting" in the system screen and press the INPUT to display the "STAF Setting" screen.

Contents of C code, M code and M maintenance code can be displayed. Search is possible by key input.

TAF SET	UP	0091
OG	RESET DryRun MILock Chuck IN	NOOO
0.Code		[F:+OEM#STAF#6_STD_UK.TXT]
Code	Contents	^
G000	POSITIONING	
G001	LINEAR INTERPOLATION	
G002	CIRCULAR INTERPOLATION/HELICAL INTERPOLATION C	W
G003	CIRCULAR INTERPOLATION/HELICAL INTERPOLATION C	XCW
G004	DVELL	
G007	VIRTUAL AXIS INTERPOLATION	
G009	EXACT STOP	
G010	DATA SETTING	
G011	DATA SETTING MODE CANCEL	
G017	Xp-Yp PLANE	
	Xp:X AXIS OR ITS PARALLEL AXIS	•
G		
0.1	RTD	
Goode	più	
M/MM	ode NX	
,		
	H CODE HH CODE	
12.0	/1 /2 /3 /4 /5 /6 /7	/0 /9 /0

Fig. 12-9 STAF Setting Screen

F2/M code · Contents of each code are displaye	
	d.
F3/M maintenance code : /	
F6/SET : Corresponding machine model name is	set.

12-10 Y MENU

Bring the cursor onto the "Menu" in the system screen and press INPUT to display the Y screen.

MACHINE	2		MPF.DIR 0912.MPF			
Channel re	set					G fct.+
Program ab	orted			ROV	PRT	cramer.
MCS	Position	Rep	oos offset	Master sp	indle _{S1}	Auxiliary func.
×1	42.093	mm	0.000	Act.	731.000 rpm 🔶	Spindles
Z1	48.057	mm	0.000	Set	731.000 rpm	
B1	0.000	mm	0.000	Pos	0 deg	A -in
+ C1	207.195	deg	0.000		100.0 %	feedrate
C2	0.000	deg	0.000	Power	02 -	
				Feedrate Act. Set Tool 1 Preselect 000	[mm/min] 0.000 100.0 ≭ 0.000 D1 ≪ ed tool: ∢	Zoom act. val. Act. val. WCS
	Preset		н	andwhee INC		2

Fig. 12-10 Y Screen

13. Program

With F2/PROGRAM being pushed, Program page (Fig. 12-0) appears. Program search, editing, creation, deletion, display of an execution block, and background editing can be performed here.

- Most of the operations explained here are valid also in the overall screen programs.
 - On program execution, display is changed.Block having been executed: Background green, letters blackBlock either in execution or to be executed: Background yellow, letters blackBlock having been pre-read: NonePrevious block: Background white, letter black

Block for next following executed or part for edition : Background black, letters white

Program edit operation needs to satisfy the following conditions:

- (1) Write key needs to be included. (Not required while in background editing.)
- (2) Mode must be Edit. (Not necessary during background editing.)
- (3) It must not be while auto operation start (or hold). (Not necessary during background editing.)
- (4) No's O8000~O9999 should not be included in Edit Inhibit by parameters.

PROGRAM							00912
J06	RESET	DryRun	Lock	Chuck IN			N0000
PROGRAM							
;00912	1			303 X148.	4 Z-68	0 R3.2 J	<u>*</u>
(TL01 /	01 TL06 /	32 TLO9 /19	TL10 /52	301 Z-69.	8]		
TL07 /1	12 TL08 /	118 TL11 /1	00 TL12 /1	(150.0 J	~ 1		
04 190	0 0150.0 1	H2. U LU 7 J		300 Z-57.	0]		
NOT G50	S5000 J			K138.0 J	0.1		
NO3 000	NO L			30F Z=64. V1 49 - 0 - 1	8 J		
NO4 MO1	101			302 V145	8 7-85	254 P2 2	
1	-			GO1 X143.	2 1	. 004 No. 2 ,	·
N100 L				GOO Z-57	δĨ		
G30 U0 I	HO M40]			(132.0]			
T0100 J				301 Z-64	8]		
G1 43]				(139.6]			
699 696	S110 M08		1	300 Z-57.	0]		
GOO X85	. 499 Z5. 2	MO3]		(126.0]			
Z0, 2 J			-	301 Z-64.	8]		
001 098	X32.704 F	-2500]		(133.6 J	0.1		
GOD V18				300 Z-37. 7120 0 1	0]		
S110 L	0.01			301 7-84	9 I		
7-57 0	1			(127 B L	0 1		
X144.0	í.			GOO Z-56	857 J		
G01 Z-6	4.96 F300	L 0		(114.0]			-
DATA >				-			
CHIANDE	RACK COD	DANCE DOOD	International International		PPOOPLIN	MACRO	151
TELE VINCOR	/1 EDIT /2	EDIT /3 COP1	/4 CONVT. /5	/6	LIST /7	VAL. /B	/9 /0 🖂

Fig. 13-0 Program

13-1 Operating Key Input Area On Screen

- (1) Clearing key Input Area
 - The key input area and the warning message are deleted.
 - ① Push SHIFT and, then, CANCEL.

13-2 Displaying Program

(1) Changing Width of Program Display (Only applicable to Program page)

Display on the screen is switched from two-column display into one-column display (or vice versa).

- ① Push SHIFT and, then, ORIGIN.
- (2) Changing Half-Em/Em Character Display
 - Display on the screen is switched from half-em into em (or vice versa).
 - ① Push SHIFT and, then, HELP.
 - (a) Character type displayed on supply of power is determined by the parameter.

13-3 Creating New Program

A new program is created.

A program immediately following creation consists of \bigcirc , the input program No, " \rfloor " of line feed, and '%'.

- (1) Input \bigcirc .
- ② Input the number for the program to be created.
- ③ Push INSERT.
- Note) When 0 exists at the beginning of the input number, the program number subject to creation and the program number displayed at the beginning of the program are not the same.

Table	12-3	Example	of	creating	Program

KEY INPUT	PROGRAM NO.	PROGRAM CONTENT	
00001	1	O 0 0 0 1]	
02	2	02]	

13-4 Deleting Program

(1) Deleting Program

One program is deleted. However, a program under Edit Inhibit or while in starting cannot be deleted.

- (1) Input O.
- ② Input the program number subject to deletion.
- ③ Push DELETE .
- ④ "Delete? Y-Yes N-No" appears.
- (5) Push Y for deletion or any other key except Y not to delete.
- (2) Deleting Two or More Programs

 \rightarrow See 14-3 PROGRAM DELETION.

13-5 PROGRAM SEARCH

(1) Searching Assigned Program

A program assigned is searched. However, a p program under Display Inhibit cannot be searched.

- (1) Input O.
- ② Input the program number subject to search.
- 3 Push any of \uparrow \downarrow \rightarrow \leftarrow .
- (4) When it has been found, the program is displayed. When not, "NOT FOUND" message is displayed.
- (2) Searching Before/After Displayed Program

Programs before/after the one in display are subject to search. When the program searched is under Display Inhibit, searching is continued until a program which can be displayed is finally found.

- 1 Input 0.
- 2 To search a number larger than the one in display, push \downarrow . To search a number larger than the one in display, push \uparrow .
- ③ A program found is displayed.
- (3) Searching Out of Program list
 - \rightarrow See 14-2 PROGRAM SEARCH.

13-6 Program Copy

Contents of a program in display are copied into another program.

- (1) Input \bigcirc .
- ② Input the program number subject to copying.
- ③ Push INPUT .
- ④ The program copied is displayed.

13-7 Changing Program Number

A program in display is changed into another program.

- ① Shift the cursor to the program number.
- ② Input O.
- ③ Input the program number to be changed.
- ④ Push ALTER .
- (5) Delete the program in display and the new program is displayed.

13-8 Program Editing (Edit Mode or Background Editing)

13-8-1 Cursor Operation

The cursor normally displays a word in reverse video, which can move as follows:

- Moving in Word Unit Cursor is moved with → or ←. When it comes to the end of the screen, display is scrolled.
- (2) Moving in Block Unit

With $\downarrow \downarrow$ or $\uparrow \uparrow$, the cursor is moved. When it is at the end of the screen, display is scrolled.

Note) When a character exists in the key input area, Word Search is judged.

- \rightarrow See 13-9 WORD SEARCH.
- (3) Switching Page

With () or () , page is changed. The cursor appears at the beginning of the page.

- (4) Moving to Beginning of ProgramWith SHIFT and, then, pushed, the cursor is moved to the program head.
- (5) Moving to End of ProgramWith SHIFT and, then, Pushed, the cursor is moved to the program end.

13-8-2 Edit Operation

Use, at the cursor position, INSERT, ALTER, and DELETE for editing.

(1) INSERT

Insert, after the cursor, the content of the key input area. When insertion takes place, the cursor moves to the last work having been inserted.

(2) ALTER

The part inversely displayed by the cursor is replaced by the content of the key input area. The cursor does not make a move.

(3) DELETE

The part inversely displayed by the cursor is deleted.

Note 1) Background editing cannot deal with the same program that can apply to ordinary editing. Choose ordinary editing.

 \rightarrow See 12-11 BACKGROUND EDITING.

13-9 Word Search

As assigned number (numerical value) or work (character string) is searched.

Whether searching for a word or for a number is determined by input.

(1) Number Search

Number search includes searching with input data which consists of one alphabet (or '#') and numerals. Numerical values are identified as being differentiated between those with a decimal point and those without. Note, therefore, that "X1." and "X1000" both of which indicating the same shifting amount, are differentiated. "X0." and "X0", however, are not separated one from the other.

Example) When searching with "N10":

N10, N010, N00010, etc.

Example) When searching with "X0.1":

X0.1, X0.100, X00.10, X.1, X.100, etc.

(2) Word Search

Character string search includes all the others except number search.

- ① Input data for searching.
- ② Assign the search direction with the cursor.
 - \uparrow Searching conducted before the cursor.
 - \downarrow Searching conducted after the cursor.
- ③ When the target word is found, the cursor moves there. When it is not found, "NOT FOUND" message is displayed.
 - To halt searching, push any one key.

13-10 Background Edit (Program Screen Only)

Normally, it is impossible to observe a program while it is in execution.

Background editing has enabled editing at this stage.

The background editing operation is completely the same as that of ordinary editing. NC execution is not affected when a program is searched, a cursor moved, or a page turned. The programs here become those dedicated to background edit where NC execution is not available. Therefore, it is possible neither to edit the program being executed nor to execute the program being background edited.

(1) Switching Screen

The edit programs are displayed along with the background edit programs. With F1 / CHANGE WINDOW being pushed, the edit programs are displayed on the left side and the background edit programs on the right side. The active window (the title bar of which is the orange color) is the editable program. Pressing it again displays the editable program in full scale.

PROGRAM				00912
JOG	RESET	DryRun	Lock	Chuck IN NO000
PROGRAM				BACK GRD PROGRAM
CTL 01 / 2 TL 07 2 /104 N01 G50 J N03 G28 N04 M01 J N100 J G30 U0 T0100 J G143 J G99 G96 G00 X85 Z0.2 J G01 G98 G01 Z2. G00 X16 S110 J Z-57. 0 X144. 0 G01 Z-6 DATA	01 TL06 /: /112 TL08 W90. 0 D150 S5000 J W0 J J W0 M40 J S110 M08 . 499 Z5. 2 X32. 704 F 0 J 0 J J J 4. 96 F300	32 TL 09 /19 /118 TL11 0. O H2. O LC M03 J =2500 J	TL10 /5 /100 TL1))]	Image: Second J Image: Second J GRUNNING PROGRAM MAIN DIGITURN200 > J G50 \$1111 J G50 \$1111 J M12 J N1 G28 U0 J N1 G28 U0 J N2 G28 W0 J N2 G28 W0 J N3 M98 P6005 J N4 G04 U2.0 J N5 M01 J J J N6 G50 S2000 J N7 (T100) M40 S20 J N8 G00 Z200.0 G M03 J N9 G00 X120.0 Z150.0 J N10 G01 Z100.0 (F12.0) G98 F1000 J N11 G00 Z150.0 M41 S3600 J N11 G00 Z150.0 J N12 G01 X150.0 Z100.0 (F0.3) J N13 G00 X200.0 J N14 G28 U0 J N14 G28 U0 J N15 G28 W0 J N12 G04 P1.0 J T
	BACK GRD	RANGE PROD EDIT /a COP	RAN VORD	PROGRAM MACRO

Fig. 13-10 (a) Switching Screen

Note) Then, if you press the F2 / BACK GRD EDIT function key, the selection shifts to the front program window or back program window, which enables you to use the key and edit.

(2) Selecting Edit Program

With F2/BACK GRD EDIT pushed while in ordinary edit, background edit is selected. And, with F2/FOR GRD EDIT being pushed while in background edit, ordinary edit is selected.

PROGRAM	00912
JOG RESET DryRun Lock	Chuck IN NO000
BACK GRO PROGRAM	
BUDD DOODAY MALN DIGLTIDNOOD	:N201 X70. 0 Z150. 0 S1500 J
RUNNING PROGRAM MAIN DIGITORN200 7	1;N202 G02 X130. 0 2120. 0 130. 0 4F0. 5 7
950 S1111	N203 G03 X190 0 Z90 0 R30 L
M12 J	N204 G00 G28 U0 J
N1 G28 U0 J	N205 G28 W0 J
N2 G28 WO]	
N3 M98 P6005 J	N3 (T500)]
N4 GO4 U2. 0 J	G00 2150.0 J
	(801 X70 0 L
N6 G50 S2000	G00 G28 U0 I
N7 (T100)M40 S20 J	G28 WO J
N8 GOO Z200. 0 (MO3]	1
N9 GOO X120. 0 Z150. 0 J	N4 (T600)M41 J
N10 G01 Z100. 0 (F12. 0) G98 F1000 J	:600 Z200. 0]
N11 GUU 2150. U M41 53600 J	- X120. U 2150. U S200U J
N13 GOD X200 0 1	600 628 U0 1
N14 G28 U0 J	G28 W0 M05 J
N15 G28 WO]	604 P1.0 J
N2 G04 P1.0 J	G00 Z100. 0 J
N200 G00 Z200. 0 J	G00 X170. 0 Z20. 0 S800 M04 J
DATA >	
CHANGE FORE GRD RANGE PROGRAM HORD	/5 /6 LIST /7 VAL. /8 /9 /0

Fig. 13-10 (b) Background Programs Screen

• Ordinary edit is differentiated from background edit by its title. Ordinary edit used "Program" for its indication, while background edit uses "BG Program".

13-11 Range Assignment Edit Operation (Program Screen Only)

Two or more blocks of a program in display are collectively deleted or copied into another program.

(1) Starting Range Edit

Range editing is started.

1 Push F3/RANGE EDIT .

Function menu changes into the one for range editing.

(2) Assigning Range

assign a program for range editing.

① Push F4/RANGE SET .

The cursor changes into the framed one.

2 Assign a range.

As in ordinary cursor shifting, a range for the framed cursor can be extended with the cursor key or the page key. The area inside the frame indicate programs under range assignment.

PROGRAM							0091
EDIT	RESET	DryRun	Lock	Chuck IN			N000
FROGRAM							
: 00912				G03 X148.4	Z-68.0) R3. 2 J	
(TLOI	/01 TL06 /3	32 TLO9 /19	TL10 /52	G01 Z-69.8			
TL07 /	/112 TL08 /1	18 TL11 /1	00 TL12 /1	X150.0 J			
04 M90). O D150. O <u>H</u>	12.0L0)]		G00 Z-57. 0	1		
N <u>O1 G5</u>	io s5000 _			X138.0 J			
				G01 Z-64.8	J		
NO3 G2	28 M <u>O </u>			X142.0]			
NO4 MO	01 _			GO3 X145.6	Z-65. 3	354 R3.2]	
				G01 X147.2	-		
N100 _	100 1440			GOD Z-57. 0	1		
G30 00	<u>WO M40 J</u>			X132.0 J			
01.42				GUI 2-04.8 V120 6 1	1		
	8 S110 MOD			A138.0 J COD 7-57 O			
800 X8	5 499 75 2	พีกล		X126 0 L	1		
70.2		mod J		G01 7-64 8	1		
G01 G9	8 X32 704 F	2500 I		X133_6 L			
G01 Z2	0 1	2000 2		G00 Z-57.0			
G00 X1	60. Ő J			X120.0 J	2		
S110				G01 Z-64.8			
Z-57. 0				X127.6 J			
X144.0				G00 Z-56. 8	57 J		
G01 Z-	64.96 F3000)]		X114.0 J			
DATA	2						
		EXIT RANG	E RANGE	RM	NGE		
RAF	/1 /2	/3 EX11	/4 STORE /5	/6 DEL	LETE / 7	/8	/9 /0

Fig. 13-11 Range Assignment

Note) The block inside the frame indicates the scope assigned. Assignment can extend over two or more pages.

(3) Canceling Range Assignment

Range editing is interrupted. Range in assignment is made invalid.

- ① Push F4/RANGE SET or F3/EXIT.
 - A framed cursor is changed into an ordinary cursor, canceling a range.
- (4) Storing Range
 - A program having been assigned in range is stored.
 - Push [F5/RANGE STORE].
 A program indicated by the framed cursor is put in memory, which is stored until power is cut off. However, only the last block subject to rage assignment can be stored.
- (5) Inserting Range

a range stored program is inserted immediately after the cursor.

- ① Shift the cursor to the insertion place.
- ② Push $F6/STORE \rightarrow INSERT$.

The part having been stored in Range Store is inserted after the cursor. The cursor position stays the same.

(6) Deleting Range

A range assigned program is deleted.

① Push F7/RANGE DELETE .

A program enclosed with the framed cursor is deleted. A program having been deleted is stored until power is cut off. Only the block having been lastly subject to range deletion can be stored.

(7) Recovering Deleted Data

A range deleted program is inserted immediately after the cursor.

- ① Shift the cursor to the insertion place.
- 2 Push F8/DELETE \rightarrow INSERT.

The part having been stored in Range Delete is inserted immediately after the cursor. The cursor position stays the same.

Note) Remind that insertion takes place after the cursor.

13-12 Word Convert (Program Screen Only)

Words not yet being converted are searched in a program, which are rewritten into the converted words. Converting methods include the following two:

- (1) The applicable words are searched one by one which are converted as being confirmed.
- (2) The applicable words are converted collectively while the conversion state is displayed.

As the word searching system is the same as that for Word Search, it is either Number Search or Word Search depending on pre-converted words.

 \rightarrow 13-9 WORD SEARCH.

For example, conversion from "X.1" into "X.5" numerically corresponds each other. Those applicable to conversion includes character strings such as "X0.1", "X0.100", "X00.10", "X.1", "X.100", etc., all of which are each converted into "X.5".

- ① Pushing F5/WORD CONVT, start Word Conversion.
- 2 Input, with keys, the word before being converted and push INPUT.
- ③ Input, with keys, the word after being converted and push INPUT.

If **INPUT** is pushed without any key input for the word after conversion, the word before conversion is deleted.

PROGRAM		00912
EDIT RESET DryRun 🕷 Loci	k Chuck IN	N0000
FROGRAM		
:00912	G03 X148.4 Z-68.0 R3.2	-
TL01 /01 TL06 /32 TL09 /19 TL10 /	52 GO1 Z-69.8]	
TL07 /112 TL08 /118 TL11 /100 TL12	/1 X150.0]	
04 W90. 0 D150. 0 H2. 0 L0)]	G00 Z-57.0 J	
N01 G50 S5000 J	X138.0 J	
	G01 Z-64 8 J	
N03 G28 W0 J	:X142.0]	
NO4 MO1 J	G03 X145.6 Z-65.354 R3.2 J	
Juneo I	GU1 X147.2 J	
	GUU 2-57. 0 J	
T0100 L	1001 7-04 0 L	
G143 L	V120 6 1	
1 800 S110 MOS	800.7-57.0.1	
G00 X85 499 75 2 M03 1	X126.0 L	
Z0.2 J	G01 Z-64 8 J	
G01 G98 X32 704 F2500 J	X133.6	
G01 Z2.0 J	G00 Z-57.0 J	
G00 X160. 0 J	X120.0 J	
S110 J	G01 Z-64.8]	
Z-57.0 J	X127.6	
X144.0]	GOO Z-56.857]	
G01 Z-64.96 F3000 J	X114.0 J	-
Conversion X100.	convert X150.	
BLANKET BLANKET BLANKET EXIT		

Fig.13-12 Word Convert

- ④ Assign a search method for conversion.
 - (a) For individual search:
 - Indicate, with $\left|\uparrow\right|/\left|\downarrow\right|$, the search direction from the cursor position.
 - When a pre-converted word has been found, "Convert? Y-Yes N-No" appears.
 - To convert, push |Y|. Not to convert, push any other except |Y|.
 - Repeat the above steps until searching is ended.
 - (b) For collective convert:
 - Indicate the search direction on Function menu.

F1/BLANKET ALL	Regardless of cursor position, searching
	starts with the program head.
F2/BLANKET BEFORE	Searching takes place in the forward part
	following the cursor including the word
	with the cursor.
F3/BLANKET AFTER	Searching takes place in the backward
	part preceding the cursor including the
	word with the cursor.

Table. 12-12 Search Direction of Word Conversion

- "OK? Y-Yes N-No" appears.
- To collectively convert here, push [Y]. If not, push any other except [Y].
- ⑤ On completion of conversion, the number of words having been converted is indicated in the message "X words have been converted."
 - Word conversion, once started, lasts till it reaches the beginning or the end of a file.
 To stop halfway, push F5/EXIT.

13-13 Macro Variables

Macro variables are displayed.

 \rightarrow 6 MACRO VARIABLES.

14. Program List

The program list (Fig. 14-0) is displayed.

Not only reading the list, you can also perform searching and deletion of a program.

PROGRAM				00912
AUTO RESET DryRun Millock	Chuck IN			N0000
PROGRAM	Program List			
:00912	Program	Size(n)	Connent	-
TL01 /01 TL06 /32 TL09 /19 TL10 /52	0001	0, 1		
TL07 /112 TL08 /118 TL11 /100 TL12 /	0002	0.1		
04 W90. 0 D150. 0 H2. 0 L0) J	0003	0.1		
N01 G50 S5000 J	0004	8.5	(WOWOW)	
Jog. 000 W0 1	0005	0.1		-
NU3 G28 W0 J	0006	0.8		
NO4 MOL J	0009	0.4		
N100 L	0010	0.2		
630 LID WO M40 L	0011	0.2		
T0100	0025	0.7		
G1 43	0026	0.4		
G99 G96 S110 M08 J	0070	0.2		
GOO X85.499 Z5.2 MO3 J	0097	0.7		
Z0. 2 J	0098	0.1		
G01 G98 X32 704 F2500 J	0100	105.4		
G01 Z2.0 J	0107	0.5		
G00 X160. 0 J	0150	0.2		
S110 J	0152	0.1		
2-07. U J	0153	0.1		*
001 7-64 06 E2000 L	•			•
GOT 2-04. 90 F3000 J	Ava. 831m.	/1000 2	28/100) Sel.	0/72
DATA >				
1 HERGE DIR SET // // //5	DETAIL EX /6	IT /7	/8 /	9 /0 🗖

Fig. 14-0 Program List Screen

14-1 Program List

With F7/PROGRAM LIST pushed on Program page, the program list is displayed. With one more push, the list is erased.

As a display position differs by display method, the same operation applies.

When a list is displayed on the full screen, (Fig. 13-0) appears on the right side on the screen. When not, (Fig. 13-1a) appears on the side opposite of the selected page.

Also, as the max. number of programs for registration and the memory amount still left unused are displayed, use them for program input and editing.

The cursor is moved with $\uparrow \downarrow \rightarrow \leftarrow \textcircled{B}$

There are two kinds of program list, the one is the program list to display the program number, size and comment, the other is the program detail display 'Fig. 13-1b) to display the date instead of the comment.

Push F6/DETAIL to switch them.

PROGRAM				00912
AUTO	RESET	DryRun	M Lock	Chuck IN N0000
Program List	t			BACK GRD PROGRAM
Program	Size(m)	Connent		: 6000
0001	0.1			(RUNNING PROGRAM MAIN DIGITURN200)
0002	0.1			
0003	0.1			G50 S1111]
0004	8.5	(WONKOWD		M12 J
0005	0.1			N1 G28 UO J
0006	0.8			N2 G28 WO]
0009	0.4			N3 M98 P6005 J
0010	0.2			N4 GU4 U2. U J
0011	0.2			L IOM CH
0025	0.7			Ne 650 \$2000 L
0026	0.4			N7 (T100.)M40 S20 L
0070	0.2			N8 G00 Z200 0 (M03 1
0097	0.7			N9 GOO X120 O Z150 O J
0098	0.1			N10 G01 Z100.0 (F12.0) G98 F1000 J
0100	105.4			N11 GOO Z150.0 M41 S3600 J
0107	0.5			N12 G01 X150.0 Z100.0 (F0.3)]
0150	0.2			N13 GOD X200. 0 J
0152	0.1			N14 G28 UO J
0153	0.1			N15 G28 WO J
•			•	N2 G04 P1. 0 J
Ava. 831	/1000 (2	8/100)Sel.	0/72	N200 GOO 2200. 0 J
DATA >				
	/1 MERGE /2	JIR S	ET /4 /5	DETAIL EXIT /8 /9 /0

Fig. 14-1 (a) Program List Screen for Background Edit.

PROGRAM			00912
AUTO RESET DryRun I Lock	Chuck IN		N0000
PROGRAM	Program List		
;00912	Program	Size(m)	Date 🔺
(TL01 /01 TL06 /32 TL09 /19 TL10 /5 🥅	0001	0.1	18/05/2001 16:28:16
2 TL07 /112 TL08 /118 TL11 /100 TL1	0002	0.1	18/05/2001 16:28:16
2 /104 W90.0 D150.0 H2.0 L0 > J	0003	0.1	18/05/2001 16:28:18
NO1 G50 S5000 J	0004	8. 5	18/05/2001 19:27:02
inco coo ino d	0005	0.1	18/05/2001 16:43:14
NC3 G28 WO J	0006	0.8	18/05/2001 16:43:14
NO4 MOL J	0009	0.4	30/03/2001 10:12:19
191 CO. 1	0010	0.2	18/05/2001 16:47:54
630 H0 W0 M40 T	0011	0.2	18/05/2001 16:47:54
T0100	0025	0.7	18/05/2001 16:47:56
6143	0026	0.4	19/04/2001 09:51:48
G99 G96 S110 M08 J	0070	0.2	16/04/2001 17:46:15
GOO X85. 499 Z5. 2 MO3	0097	0.7	30/03/2001 10:12:19
Z0.2 J	0098	0.1	30/03/2001 10:12:19
G01 G98 X32. 704 F2500 J	0100	105.4	30/03/2001 10:22:12
G01 Z2.0 J	0107	0.5	30/03/2001 10:12:26
G00 X160.0 J	0150	0.2	30/03/2001 10:12:26
S110 J	0152	0.1	30/03/2001 10:12:26
Z-57.0 J	0153	0.1	30/03/2001 10:12:26 📼
X144.0 J	1		•
GUT Z-64.96 F3000 J	Ava. 831m/	/1000 2	8/100)Sel. 0/72
DATA			
MERCE DIR SET	DETAIL EXI	IT	
EX.) /1 /2 /3 /4 /5	/6	17	/0 /9 /0 🖂

Fig. 14-1 (b) Program Change

The comment for the program detailed display indicates the one immediately following O number in a program. If not existing, no display takes place. Max. 16 characters can be displayed. The size for output is 0.1m each. However, depending on memory control, it may slightly differ from the actual tape length.

14-2 Program Search

Program search can be performed as follows while Program List or Program Detail is in display.

- (1) Searching with Program List
 - Empty the key input area.
 - ② Move the cursor to the program number subject to search.
 - ③ With INPUT pushed, a program is changed over.
- (2) Searching by Key Input
 - 1 Input 0.
 - ② Input the program number subject to search.

 - ④ On finding, the program is displayed. If not, "NOT FOUND" message appears.

14-3 Program Deletion

Program deletion can be performed as follows while Program List or Program Detail is in display, provided that the following conditions are satisfied.

- (a) Write key should be included.
- (b) It is in Edit mode. (Not necessary while in background editing.)
- (c) It is not in auto operation start (or halt). (Not necessary while in background editing.)
- (d) For O8000~O9999, it should not Edit Prohibit.
- (1) Deletion from Program List

A program at the cursor position on the program list is deleted.

- ① Empty the key input area.
- ② Shift the cursor to the program number subject to deletion.
- ③ Push DELETE .
- ④ "Delete? Y-Yes N-No" appears.
- (5) Push [Y] for deletion. If not, push any other key except [Y].
- (2) Collective Deletion by Program Selection

A program selected on the program list is deleted.

- Select a program to be deleted and put ^(*) in front of the number. To select the all programs, push ORIGIN. To select them one by one, move the cursor to a program to be selected and push SPACE.
 To cancel it, push either ORIGIN or SPACE.
- ② Push DELETE .
- ③ "Delete? Y-Yes N-No" appears.
- ④ To delete, push Y. If not, push any other key except Y.
- Note 1) Before deleting, search the program and confirm program content. A program having been deleted cannot be recovered.
- Note 2) When a program in display has been deleted, the program of the next following program number is displayed.

14-4 Program Merging

Following the program displayed by the program list, another program indicated by the cursor on the program list can be merged.

- ① Search the program to which a program is merged.
- ② Shift the cursor to the program to be merged on the program list.
- ③ Push F2/MERGE .
- ④ "Merge? Y-Yes N-No" appears.
- (5) To merge, push |Y|. If not, push any other key except |Y|.
- 6 Start merging.
- ⑦ On ending, the program is displayed all over again from the beginning. At the merging section, the numbers in the O-number of the merged program alone are left behind.
- Belete? Y-Yes N-No" appears.
 To delete the program merged at the end, push Y. To leave it, push any other key except Y.

14-5 Directory Setting

The program memory is 1000m x100 lines, and you can hold several memories of the same memory on the hard disk. When the memory gets full or when you have to register a different NC program for different work, you can have a different memory without deleting all by changing to a different directory. If you want to restore the original state, you only have to select again the previous directory.

The program with a different directory cannot be called out bilaterally with M98, etc. However, $O8000 \sim O9999$ always reside in any directory as macro programs, call-out or edit is possible. The file operation in the directory setting screen needs to be [Writing key - Writing] [Edit Mode]. Move the cursor to each list using function F1, F2 and F3. In each list, you can delete the file/directory by attaching a check mark to them.

DIR SET								00912
EDIT	RESET	DryRun	Lock Cl	huck OUT				N0000
SET	YOSHI							
DIRECTORY	LIST		FILE LIST					
DIRECTORY	NAME	Date	File name		Size	Date		
🗖 ASAH I		2001.05.10	0001		0.1	2001.05.18	16:28:16	
HIKOBOSI		2001.05.10	0002		0.1	2001.05.18	16:28:16	_
HOSHISAN	4	2001.05.10	0003		0.1	2001.05.18	16:28:18	
■Kama		2001.05.10	0004		8.5	2001.05.18	19:27:02	
NONSAN		2001.05.23	0005		0.1	2001.05.18	16:43:14	
TUK I SAMA	1	2001.05.10	0006		0.7	2001.05.18	16:43:14	
UMIYAMA		2001.05.10	0009		0.4	2001.03.30	10:12:19	
USER USER		2001.05.17	0010		0.2	2001.05.18	16:47:54	
YOSHI		2001.05.23	0011		0.2	2001.05.18	16:47:54	
			0025		0.6	2001.05.18	16:47:56	-
			00000-000	0.1157	~ ~	0001-04-10	0.51.40	-
			08000-0991	A LIST				
			File name		Size	Date		
			8000		0.3	2001.05.21	14:54:14	
			9999		0.1	2001.05.21	14:46:44	
	FILE	00000 EXIT	NEW D	ENHE COPY				
REAR LIST /	LIST /:	LIST /3	/4 /5	/6	17	/8	/9	/0 🗖

Fig.14-5

SET	:	The directory name currently being selected is displayed.
	·	All of the existing directories are displayed.
FILE LIST	•	All of the programs that exist in the directory where the
		cursor is placed in the directory list are displayed.
O8000~O9999 LIST	:	A list of the macro program is displayed.
F1/DIRECTORY LIST	:	The cursor is moved to the directory list.
F2/FILE LIST	:	The cursor is moved to the file list.
F3/O8000 LIST	:	The cursor is moved to the O8000~O9999 list.
F4/EXIT	:	Returns to the program list screen.
F5/NEW	:	A directory is newly created.
F6/RENAME	:	A directory name is changed.
F7/DIR COPY	:	A directory is copied.
F8/FILE COPY	:	A file is copied between different directories.
INPUT	:	Directory setting is made.
DELETE	:	A directory or file is deleted.
SPACE	:	A Check mark is attached/removed.
ORIGIN	:	Check marks are attached to/removed from all.

14-5-1 Directory setting

The directory to be used is selected.

- 1 Press F1/DIRECTORY LIST and move the cursor to the directory list.
- 2 Place the cursor on the directory to be used.
- ③ Press INPUT .
- (4) You are asked OK?, then press Y.

After the directory setting is completed, the screen is automatically changed to the program list screen. The program which has been searched so far becomes void, so search the program.

14-5-2 Directory Creation

A directory is newly created. Directories can be registered up to 10 (up to 100 at option). However, the "USER" directory is presumed to be always existing (cannot be deleted). The directory must be named with less than 8 alpha-numeric characters. The name consisting of numbers only like 1234 is not accepted, where alphabetical character must always be included like A1234. A decimal point cannot be used either.

- 1 Press F1/DIRECTORY LIST and place the cursor on the directory list.
- 2 Input the directory name from the keys.
- ③ Press F5/NEW .

14-5-3 Delete of Directory

Unnecessary directories can be deleted.

- 1 Press F1/DIRECTORY LIST and place the cursor on the directory list.
- 2 Place the cursor on the directory you want to delete.
- ③ Press DELETE .
- (4) "You are asked OK?", then press Y.

The USER directory cannot be deleted, as it is held as standard.

14-5-4 Change of Directory

The directory name can be changed.

- 1 Press F1/DIRECTORY LIST and place the cursor on the directory list.
- 2 Place the cursor on the directory for which you want to change the name.
- ③ Input the directory name from the keys.
- ④ Press F6/RENAME .

14-5-5 Copy of Directory

A directory is copied.

- 1 Press F1/DIRECTORY LIST and place the cursor on the directory list.
- (2) Place the cursor on the directory to be copied.
- ③ Input the directory name from the keys.
- ④ Press F7/DIR COPY .

14-5-6 Copy of File

A program can be copied between different directories.

- 1 Press F2/FILE LIST and place the cursor on the file list.
- (2) Attach a check mark to the file you want to copy.

Using SPACE attaches the check mark one by one, using ORIGIN attaches it to all.

- ③ Press F8/FILE COPY , which makes the O8000 list the file copy list. The cursor is moved to the directory list.
- ④ Place the cursor on the directory which is the destination of the copying.
- 5 Press F9/FILE COPY EXE .
- 6 "You are asked OK?", then press Y.

15. Input / Output

With F8/IN/OUT pushed, the data I/O screen is displayed.

All the operations relating to I/O such as RS232C, PC Card and NetWork are performed here. The program list is displayed on the right side of the page, the data setting table (various data setting) on the left, and the monitor screen at the bottom left-hand corner.

As I/O state being displayed on the monitor screen, use it to confirm operation and to check collation errors.



Fig. 15-0 I/0 Screen

(1) F1/Input

Input the external unit data into NC main body.

- ① Connect the external unit.
- ② Set item on the data setting table to the setting of the external unit.
- ③ Set the external unit to Output Standby state. (Make sure that all the communication lamps are turned green.)
- ④ With F1/INPUT pushed, input is started.

(2) F2/Output

Data of the NC main body are output into the external unit.

- ① Connect the external unit.
- 2 Set the item of the data setting table to the setting of the external unit.
- ③ Set the external unit to Output Standby state. (Make sure that all the communication lamps are turned green.)
- ④ With F2/OUTPUT pushed, output is started.

(3) F3/Verify

Data are verified between the external unit and the NC main body. Verification cannot be made depending on data. See applicable data.

- ① Connect the external unit.
- ② Set item of the data setting table to the setting of the external unit.
- ③ Set the external unit to Output Standby state.
- ④ With F3/VERIFY , collation is started.
- (4) F4/Abort

Input, output, and collation are interrupted.

(5) F5/View

Displays the leading part of the 0 number indicated by the reversed cursor in the program list at the right of the screen.

Only NC program is valid.

(6) F6/Set

Sets the type of the data sent or received and the communication means. See "14.2 Setting Data" for the details.

(7) F7/List Xchag

Alternately changes the comment display and the time stamp display in the program list.

(8) F0/DIR

Valid only when PC card and UUP folder are used.

You can confirm the content of the PC card and UUP folder as well as delete the folder or file.

When PC card is used, you can also create or delete a sub folder.

• File select window

The file select window is valid only when PC card and UUP folder are used.

Pressing F0/DIR opens the following file select window.

UUP FOLDER	Filenane	Size Date	+
	100	42181 30/03/2001 10:21	:34
lder	4	3419 19/04/2001 19:29	:24
older	6	311 19/04/2001 19:29	:56
§D:¥	AAA	123 18/05/2001 16:26	:22
UUPTMP	AAA. TXT	4691 25/06/2001 19:35	:36
	AUXTEHP. TXT	332820 26/06/2001 17:57	12
	BBB	3779 18/05/2001 16:43	3:02
	000	467 18/05/2001 16:47	:34
	1200323.131	99008 24/02/2001 11:42	:30
	J1. Jpg	82004 2870672001 18:24 51719 09/06/2001 14:29	:08
	75. 106	51718 2870672001 14:33 eepee00/06/2001 14:33	10
	July in the second seco	43650 08/06/2001 14:42	-06
	.15 ioz	61177 98/06/2001 14:33	30 1

Fig. 15-0-1 File select window

(1) F1/Folder Sel

Moves the cursor to the directory area.

After that, you can change the directory using the UP and DOWN key.

(2) F2/File List Sel

Moves the cursor to the file list area. You can specify the file using the cursor UP and DOWN key.

(3) F3/File Name Selection (Only when output)

Moves the cursor to the file name input area. Enter here a character string as a new file name.

(4) F5/View

Displays the leading part of the file content indicated by the reversed cursor.

(5) F6/Folder Make

Valid when the cursor is in the folder area.

You can add a folder when PC card is used.

(6) F8/DELETE

Deletes a folder or file indicated by the cursor.

(7) F0/CANCEL

Stops the operation of the file select window.

• To use UUP folder.

The UUP folder corresponds to the PC card slot in the virtual media where LAN is used in the place of the PC card. It is seen as a common virtual drive shared by an external personal computer via LAN, where you can directly transfer a file to this folder. After that, you can input/ out by the same operation as the PC card. Meanwhile, to connect this to LAN as a virtual drive, you must both set the NC side and the personal computer side.

15-1 Program List

- (1) Program Selection (Used when inputting/outputting a program)
 - ① Move the cursor to the program you want to select.
 - ② Press SPACE .

A check mark appears in front of the program selected.

To select/cancel all programs, press ORIGIN .

(2) Program Clear in the List

```
If you select a program and press DELETE, you are asked "Is it OK to clear? Yes (Y) No (N)". Press Y to clear.
```

15-2 Setting Data

Bring the cursor onto the item to be set and press INPUT, which displays the items to be selected.

Followings are the contents of the data to be set.

(1) Data

Select from among program, multi, work coordinate, tool, common variable, etc.

(2) Port

Select from among; PC-CARD UUP folder RSI

(3) Baud Rate

Select from among 1200, 2400, 4800, 9600, 19200, 38400 and 56000

- (4) Stop Bit
 - Select from: 8 bits 7 bits

(5) Parity

Select from among: None Even (E) Odd (O)

- (6) Stop BitSelect from:1 bit2 bits
- (7) Cord ConversionSelect from among:ASCIIISOEIA
- (8) ControlSelect from among:NoneHard RTS/CTSSoft XON/XOFF
- (9) DC3Select from:13H93H
- (10) Output Line Feed

Select from among: CR + LF LF LF + CR

16. Test Operation

If you press F9/TEST RUN while the overall screen is displayed, the function keys to set the signals used for the test operation are displayed (Fig. 16.0).

If you press $\boxed{F2/DRY RUN}$, you are asked "Is it OK? Y-Yes N-No". Pressing \boxed{Y} changed the dry run setting (ON, OFF alternately changes).

When executing the dry run, the F2/DRY RUN display looks like being sunk.

In the same way, you can change the setting of the machine lock using $\boxed{F3/MACHINE LOCK}$. The color of Dry Run and Machine Lock at the top center of the screen changes.



Fig. 16-0 Test Operation

17. Manual Operation

If you press F0/MANUAL OPERATION when the overall screen is displayed, the function keys to set various functions used for the manual operation are displayed(Fig. 17-0).

Pressing the various function keys, the setting of the selected function changes (ON OFF alternately changes). While the various functions are ON, the display of the selected function looks like being sunk.

Following manual operation is possible.

F1/Chuck Outside F2/Chuck Inside F3/Spindle Low F4/Spindle Middle F5/Spindle High F6/Air Blow Chuck F7/Air Blow Sppindle F8/Light F9/Next \rightarrow (F1/Turn Tool, F2/C Axis) F0/EXIT

WAIN	00912
AUTO RESET DryRun ON Lock	Chuck IN N0000
	DRAPHIC
CTL01 /01 TL06 /32 TL09 /19 TL10 /5 2 TL07 /112 TL08 /118 TL11 /100 TL1 2 /104 W90.0 D150.0 H2.0 L0) J N01 G50 S5000 J J N03 G28 W0 J N03 G28 W0 J N04 M01 J J N100 J	
Data >	иваоцит фізт то до
Tool T0100 GE0H. #EAR	X 490.586 X 0.000
001 TURN X 0.000 U 0.000 ROUGH FACE Z 10.000 W 0.000	Z 244.857 Z 0.000
R 0.312 0 0.000	ZB 0.000 ZB 0.000
H 0.000 J 0.000	C1 345.339 C1 0.000
Theory 5 That for the State of the State	C2 0.000 C2 0.000
REAL S 731[nin ⁻¹] F S 0[mn] CLUMP S 3000[nin ⁻¹]	Chuck 0[N] T/S 0[N]
	2001/05/22 12:15:03
CHUCK CHUCK SPINDLE SPINDLE SPINDLE SPINDLE HIDH /6	AIR BLOW AIR BLOW LIGHT ONmext EXIT DHUCK /6 SPINDLE/7 /8 -/9 /0

Fig. 17-0 Manual Operation

18. User Screen

Press \land key to change the function key and press $\boxed{F1/USER}$ to display the user screen in the window screen.

If you register photo or video data beforehand, you can display an arbitrary screen.

The user screen is a screen to register an image or animation on the NC and display them. For registering the image and animation, 100M byte space is made free on the hard disk. You can register one image or animation to each function key $F1 \sim F8$ and vertical function $VF1 \sim VF8$, which makes 16 in total, and making them all one channel, up to 8 channels can be used for the registration, i.e. 16×8 channels = 128 can be registered.

The image that can be displayed is BMP format (.BMP) or JPEG format (.JPEG) and the animation that can be displayed is AVI format (.AVI).



Fig. 18-0 User Screen

18-1 How to oprate User Screen

The image and animation registered are displayed by only pressing the function keys.

F1~F8	:	The image and animation registered are displayed.
VF1~VF8	:	The image and animation registered are displayed.
F9/CHANNEL>>>	:	Changes to the next channel.
AUX	:	Changes to the previous channel.
F0/SET	:	Moves to the screen to register the image and animation.

In case of an animation, the following function appears, which enables a pause or frame feed.

		\square	11	-			0
Prev	 Next	Play (a	Pause	Back (r	Step (c	Stop (7	

Fig. 18-1 Function Keys for Animation

F1/Prev	:	Winds back the animation up to the start.
F2/Next	:	Forward the animation up to the end.
F3/Play	:	Starts playing from a stop state.
F4/Pause	:	Enables/cancels a pause.
F5/Back	:	Feeds frames backwards.
F6/Step	:	Feeds frames.
F7/Stop	:	Temporarily stops playing.
F0/End	:	End the animation.

18-2 Setting Screen

This is a screen to set which image or animation is to be registered in the function keys of the user screen.

USERS SC	REEN		0000
009	RESET DEYKUN	LOCK Ghuck	14 4000
	Channel	2	
No.	Title	File name	
01	PARTS1	BUHIN2-1. bep	
02	PARTS2		
04	PARTS3		
05	PORK1		RIHIN2-1, ban
06	MORK2		J1. jpg
07	MORK3		J2. jpg
08			J JP8 T4. ipc
10			J5. jpg
11	PICTURE1		J6. jpg
12	PICTURE2		J8. jpg
13	PICTURES		
14	PTGTURE4		
16			
17			
18			
Tit	le		
SAVE		E CHANNEL IN / OUT	T CHANNEL CHANNEL EXIT ►

Fig. 18-2 Setting Screen

F1/SAVE	:	Saves the data and enables the registration setting.
F3/DATA	:	Moves the cursor to the function registration list.
F4/FILE LIST	:	Moves the cursor to the file list screen for image and animation data.
F5/CHANNEL	:	Moves the cursor to the channel name setting.
F6/IN/OUT	:	Changes the screen to the one that inputs/outputs the image and
		animation data to be registered.
F8/CHANNEL<<<	:	Changes the channel to the previous one.
F9/CHANNEL>>>	:	Changes the channel to the next one.
F0/EXIT	:	Returns to the user screen.
SHIFT + INPUT	:	Copies the data in the table to the key input area.

18-2-1 How to register

Registration is made by setting the following items in the table for each channel.

(1) Number

Represents the number of functions.

- 01~08 correspond to the horizontal functions $F1 \sim F8$.
- 11 ~18 correspond to the vertical functions $VF1 \sim VF8$
- (2) Title

Registers the characters to be displayed in the function menu. Input the name from keys and set it with INOUT.

(3) File name

Registers a file name for the image and animation which is displayed when the function is pressed. Input it directly from keys or select from the file list.

① Press the function F2/FILE LIST and move the cursor to the file list.

2 Using cursor keys $\boxed{}$ $\boxed{}$ $\boxed{}$, select the file and register it with $\boxed{}$ INOUT $\boxed{}$.

As there are 8 channels, each channel name can be attached.

(4) Channel name

There is an area to set the channel name at the upper left corner of the screen. Move the cursor using F5/CHANNEL, input the name from keys and set it with INPUT. After the setting, pressing F1/SAVE enables the registration.

If it is not saved, when you change the screen, you are asked "Do you save?". Then if you press Y, the result will be the same as you save it.

If you turn off the power without saving, or if you press \boxed{N} when you are asked "Do you save?", the setting data become void.

18-3 Input/Output

Executes input/output of image and animation data.

The destination of the input/output is the "memory card" or "UUP folder".



Fig. 18-3 Input/Output Screen

F1/Drive Change	:	Changes between memory card/UUP folder.
F2/Folder Select	:	Changes the folder (directory) as the destination of input/output.
F3/File Select	:	Changes the direction of transmission as input/output destination \rightarrow NC.
F4/User Select	:	Changes the direction of transmission as NC \rightarrow input/output destination.
F5/Copy Exe.	:	Copies the selected file towards the transmission direction.
F6/EXIT	:	Setting screen.
F7/LIST Change	:	Changes the list screen to size \rightarrow date.
F8/CHANNEL<<<	:	Changes the screen to the previous one.
F9CHANNEL>>>	:	Changes the screen to the next one.
18-3-1 How to Register

The left side of the screen is made the destination of input/output and the right side is made the pcFLexi side.

- (1) Using F7/CHANNEL<<< F/8CHANNEL>>> , select the channel of the user screen. The image and animation files registered in each channel are displayed in the user screen list.
- (2) Press F2/FOLDER SELECT and move the cursor to the folder of the input/output destination.

Select the folder moving the cursor upward and downward and press INPUT, then the folder is selected.

The content of the folder selected is displayed in the file list.

- (3) Press F3/FILE LIST and move the cursor to the file list of the input/output destination. Using SPACE, attach a check mark to the file you want to copy (ORIGIN) can select all).
- (4) F5/COPY EXE. starts copying (If there is no check mark attached, the file where the cursor is positioned is copied).

18-3-2 File handling

When the cursor is positioned to the file list or user file list, the following keys are enabled. In case of the user file list especially, as there is limitation that is 100M, delete redundant files. The vacant capacity is displayed below the list.

SPACE : Attaches a check mark.
ORIGIN : Attaches or removes check marks to or from all files.
DELETE : Deletes the file with a check mark attached. (If there are no check mark, the file where the cursor is positioned is deleted.)

19. Q Setter Setting

Press \land and $\boxed{F8/Q \text{ SETTER SETTING}}$, and the Q setter setting screen is displayed (Fig. 19.0), where you can change the sensor position of the Q setter.

9 Setter Setting	00912
AUTO RESET DryRun ON N Lock Chuck IN	N0000
Alter Value (X-AXIS)	
SELECT C IN A:Outside of X -180.000 B:Inside of X -220.000	
SIZE 0.000 C:Outside of Z -280.000	
MEAS.VAL 0.000 D:Inside of Z -320.000	
COMPENS 0.000	
ALTER C RUN @ STOP	
P:ABS =	
	/0

Fig. 19-0 Q setter setting

20. Ladder Live Line Display

20-1 Ladder Live Line Display Screen

(Explanation for the case there is no mouse)

- In the system screen, bring the cursor onto the [30. Y Menu] and press INPUT to display the Y screen, then press MENU SELECT in the operation panel and press > key to assign Step7 to the function key.
- ② Press the function key of Step7, and the SIMATIC Manager screen boots up.



Fig. 20-1 (a) Y Screen

③ Press Alt key to open the sub menu of the File using F key. Using the cursor ↑ ↓ keys, move the cursor to the Open in the sub menu and press INPUT.

	<u>File</u> P <u>L</u> C <u>V</u> iew <u>O</u> ptions <u>W</u> indow <u>H</u> elp	
/	<u>N</u> ew	Ctrl+N
	'New Project' Wizard	
\square	<u>O</u> pen	Ctrl+O
3	Open Version 1 Projec <u>t</u>	
	S7 Memory Card	•
	<u>W</u> inLC file	•
	<u>D</u> elete	
	R <u>e</u> organize	
	<u>M</u> anage	
	<u>A</u> rchive	
	Retrie <u>v</u> e	
	Page Setup	
	Labeling fields	
	P <u>r</u> int Setup	
	1 k7test (Project) F:\OEM\STEP7\S7proj\K7test_1	
	<u>2</u> k7test (Project) F:\Add_on\Step7\S7proj\K7test_1	
	<u>3</u> S7_Pro1 (Project) F:\add_on\Step7\S7proj\S7_Pro1	
	4 arie_1219 (Project) F:\Add_on\Step7\S7proj\Arie_121	
	E <u>x</u> it	Alt+F4

Fig. 20-1 (b) File Open Screen

	Open		×
	User projects Li	braries Sample projects	
	Name	Storage path	
/	k7test k7test S7_Pro1	F:\Add_on\Step7\S7proj\K7 F:\OEM\STEP7\S7proj\K7TI F:\add_on\Step7\S7proj\S7_	TEST_1 EST_1 _Pro1
4	•		Þ
\setminus		Selected	
/	User Projects Libraries		
	Sample Projects		<u>B</u> rowse
	ОК	Cancel	Help

Fig. 20-1 (c) Project Select Screen

(5) Using the cursor \rightarrow key, bring down the tree in the screen as far as it reaches the folder of S7 Program, then open the Blocks folder with the \downarrow key.



Fig. 20-1 (d) Block Select Screen

6 Move the cursor to the right window with TAB key, select the file you want to refer to with the cursor \uparrow \downarrow key then press INPUT key, and the ladder screen is displayed.

LAD/STL/FBD - [FB40 Ele Edit Insert PLC	 k7test\yasmac k7\PL0 Debug View Options W 	C315-2DP M/S 2AF03 indow 실려p	1	_ 6
	<u>国民 ママ 第</u> 正光の日日コ	≝ <u>⊐</u> ∃ ¥?		
ddress Declaration	Bane	Туре	Start value	Conneat
0.0 in	STARTUP	BOOL	FALSE	INPUT PL
_				-
-				
Comment:				
I25.7	DB10.DBX10 DE 6.1 9.	810.DEX10 5 #START	UP #svon_aux	
Comment: I25.7 #svon_aux I25. Network 6: NOT STAND	DB10.DBX10 DE 6.1 9. 0	310.DEX10 5 ∉START −L/	UP ∉svon_eux ()	

Fig. 20-1 (e) Ladder Screen

⑦ When the ladder

live line display is finished, press Alt key	, open the File mei	nu with	
F key, select Exit with the cursor \uparrow \downarrow	key and press	INPUT	key to close the
window.			

8 Press Alt key, open the Debug menu with D key, move the cursor to the Monitor with the cursor \uparrow \downarrow and press INPUT key. Then you can see the status of the ladder.

8	M <u>o</u> nitor Call Environment O <u>p</u> eration	Ctrl+F7
	<u>M</u> odify Address Modify Address to <u>0</u> Modify Address to <u>1</u>	
	Set <u>B</u> reakpoint Delete <u>A</u> ll Breakpoints B <u>r</u> eakpoints Active <u>S</u> how Next Breakpoint	Ctrl+H Ctrl+Shift+H F4
	Res <u>u</u> me E <u>x</u> ecute Next Statement <u>E</u> xecute Call	Ctrl+F8 Ctrl+F9 Ctrl+F12

GLAD/STL/HUD -[En pap - Kriesciyasilar	: k7\PLC315-2DP M7S 2	APU3] UNLINE	_ 5
i≱ <u>F</u> ile <u>E</u> dit jncert i	PLC Debug Yiew Optio	ns <u>W</u> indow <u>H</u> elp		_ 6
D # 밝 티 #		院會 🗢		
er 1521 🗈	照 표생·이머니	, it R		
Address Declara	tion Name	Туре	Start value	Conneat
0.0 in	STARTUP	BOOL	FALSE	INPUT PLC
				•
Network 51 Serv	o power on			
Comments				
	DB10.DBX1	0 DB10.DBX10		
125.7	D810.DBX1 6.1	0 DB10.DEX10 9.5 #STA	ARTUP ∦svon_aux	
125.7	DB10.DBX1 6.1	0 DB10.DBX10 9.5 #STA	RTUP ∉svon_eux	
125.7	DB10.DBX1 6.1	0 DB10.DBX10 9.5 ∉STX	RTUP ∉svon_oux	
I25.7	D810.DBX1 6.1 125.0	0 DB10.DBX10 9.5 ∉STA	ARTUP ∯svon_oux	
I25.7	D810.DBX1 6.1 125.0	0 DB10.DBX10 9.5 #STA	ARTUP ∯svon_eax	
I25.7	D810.DBX1 6.1 125.0	0 DB10.DBX10 9.5 #3TA	ARTUP ∦svon_eax	
I25.7	D810.DBX1 6.1 125.0	0 DB10.DBX10 9.5 #3TA	ARTUP ∉svon_eaac	
I25.7 #SVON_AUX	D810.DBX1 6.1 125.0	0 DB10.DBX10 9.5 #3TA	ARTUP ∉svon_eaac	

Fig. 20-1 (f) Ladder Status Display Screen

20-2 Search

① Press Alt key, open the Edit menu with E key, move the cursor to the Find and Replace with the cursor ↑↓ key and press INPUT key. Then the Find and Replace window is displayed.

	<u>U</u> ndo <u>R</u> edo	Ctrl+Z Ctrl+Y
	Cu <u>t</u> Copy <u>P</u> aste	Ctrl+X Ctrl+C Ctrl+V
	Dejete	Del
	Select <u>A</u> ll	Ctrl+A
	<u>F</u> ind/Replace	Ctrl+F
	<u>G</u> o To	•
1	Object Properties Sp <u>e</u> cial Object Properties Connections	Alt+Return ▶
	Ope <u>n</u> Block <u>B</u> lock Call	Ctrl+Alt+0 ▶
	Initialize Data Block Create Net <u>w</u> ork Template <u>S</u> how Picture	

Fig. 20-2 (a) Search Select Screen

② Enter the data to be searched and press INPUT key, and search is executed.

	Find/Replace		×
	Find <u>w</u> hat:	Replace with:	▼ << Reduced
2	From Cursor Down	rom Cursor C <u>A</u> ll P	C <u>H</u> ighlight
	Find Whole Words Only	□ <u>M</u> atch Case	
	Eind Replace	Replace All	e Help

Fig. 20-2 (b) Search Window

20-3 Cross Reference

① Press Alt key, open the Options menu with O key, move the cursor to the Reference Data → Display with the cursor \uparrow \downarrow \rightarrow key and press INPUT key. Then you can check in which block the contact point or coil is used.



Fig. 20-3 (a) Reference Data Select Screen

② As a message that the data are filtered is displayed, press INPUT and proceed to the next.



Fig. 20-3 (b) Filter Select Window

③ Check the cross reference and press INPUT , and the cross reference boots up.



Fig. 20-3 (c) Cross Reference Select Window

			dendo kraroc	313-201	- m/a	296.031		- 121
Edit View Wind	dow <u>H</u> elp							_ 0
15月前(6)*2	20	k ?						
Symbol .	Block	Type	Language	Deta	ils 🛛			
gp par.IN45	FC3	R	STL	NV	1	Sta	1	/A
	FB17	R	STL	NW	1	Sta	1	/A
	FC9	R	STL	NV	1	Sta	1	/8
	FC2		STL	NV	1	Sta	84	/\$
	FC2	R	STL	NV	1	Sta	82	/A
	FC2		STL	NW	1	Sta	76	/5
	FB1	R	STL	NV	1	Sta	138	/A
	FC1	υ	STL	NV	1	Sta	2	/S
	FC1		STL	NV	1	Sta	1025	/5
NC.A_EHE	FB43		LAD	NV	1	/-		
NC.A EME	FB43	R	LAD	NW	2	/8N		
NC.A ENE	FB43		LAD	NV	2	/=		
NC.A Inc	FC19		STL	NW	1	Sta	54	/\$
NC.A Inc	FC26	U	STL	NV	1	Sta	48	/5
NC.A Inc	FC24		STL	NV	1	Sta	57	/\$
NC.A Inc	FC25	U	STL	NM	1	Sta	49	/S
NC. F57 3	08108	R	LAD	NV	2	/0		
NC. F57_3	08108	R	LAD	NW	2	/0N		
NC.E NCK	FC2	R	STL	NW	1	Sta	65	/AN
NC.E_NCK	FC2		STL	NV	1	Sta	1.96	/5
115 P 1151	F 0.0	n.	0.71			~	+ 0.0	141
							_	
	Symbol gp par.INA5 gp par.INA5 NC.A_EHE NC.A_EHE NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc NC.A_Inc	Symbol Block gp par.IN45 FC3 F617 FC9 FC2 FC2 FC2 FC1 FC1 FC1 NC.A_EHE FB43 NC.A_EHE FB43 NC.A_EHE FC4 NC.A_EHE FC4 NC.A_EHE FC4 NC.A_Inc FC2 NC.A_Inc FC2 NC.A_Inc FC2 NC.A_Inc FC2 NC.A_Inc FC2 NC.A_Inc FC2 NC.F57_3 0B100 NC.E_NCK FC2 NC.E_NCK FC2 NC.E_NCK FC2	Symbol Block Type gp par.INM5 FC3 R FC9 R FC2 W FC2 W FC2 W FC2 W FC1 W FC1 W FC1 W NC.A_ENE FBA3 NC.A_ENE FBA3 NC.A_ENE FC24 NC.A_ENE FBA3 NC.A_ENE FC3 NC.A_ENE FC4 NC.A_ENE FC24 NC.A_ENE FC24 NC.A_Inc FC24 NC.A_Inc FC25 NC.A_Inc FC25 NC.A_Inc FC25 NC.A_Inc FC2 NC.A_Inc FC2 <	Symbol Block Type Language gp par.INMS FC3 R STL FB17 R STL FC9 R STL FC2 W STL FC2 R STL FC2 W STL FC2 W STL FC2 W STL FC1 W STL FC1 W STL FC1 W STL NC.A_ENE FB43 M NC.A_ENE FB43 W NC.A_INC FC26 W NC.A_INC FC26 W NC.A_INC FC26 W NC.A_INC FC26 W NC.A_INC FC25 W NC.A_INC FC25 W NC.A_INC FC2 R NC.A_INC FC2 R NC.A_INC FC2 R NC.A_INC	Symbol Block Type Language Deta gp par.INW5 FC3 R STL NW FC9 R STL NW FC2 W STL NW FC1 W STL NW NC.A_ENE FB43 M LAD NW NC.A_ENE FB43 M LAD NW NC.A_ENE FB43 M LAD NW NC.A_ENE FC19 M STL NW NC.A_INC FC26 M STL NW NC.A_INC FC25 M STL NW NC.A_INC FC25 M STL NW NC.A_INC FC2 <t< td=""><td>Symbol Block Type Language Details gp par.IN45 FC3 R STL NV 1 FB17 R STL NV 1 FC9 R STL NV 1 FC2 W STL NV 1 FC2 R STL NV 1 FC2 R STL NV 1 FC2 M STL NV 1 FC1 M STL NV 1 FC1 M STL NV 1 NC.A_ENE FB43 M LAD NV 2 NC.A_ENE FB43 M LAD NV 2 NC.A_ENE FB43 M LAD NV 2 NC.A_INC FC26 M STL NV 1 NC.A_INC FC25 M STL NV 1 NC.A_INC FC25</td><td>Symbol Block Type Language Details gp par.INMS FC3 R STL NW 1 Sta gp par.INMS FC3 R STL NW 1 Sta FC9 R STL NW 1 Sta FC9 R STL NW 1 Sta FC2 W STL NW 1 Sta FC2 R STL NW 1 Sta FC2 W STL NW 1 Sta FC1 W STL NW 1 Sta FC1 W STL NW 1 Sta NC.A_ENE FB43 M LAD NW 1 /= NC.A_ENE FB43 W LAD NW 2 /= NC.A_ENE FB43 W LAD NW 2 /= NC.A_INC FC26 W</td><td>Symbol Block Type Language Details gp par.INMS FC3 R STL NW 1 Sta 1 FC9 R STL NW 1 Sta 1 FC9 R STL NW 1 Sta 1 FC2 W STL NW 1 Sta 1 FC2 R STL NW 1 Sta 84 FC2 R STL NW 1 Sta 82 FC2 V STL NW 1 Sta 130 FC1 W STL NW 1 Sta 122 NC.A_ENE FB43 M LAD NW 1 /= NC.A_ENE FB43 W LAD NW 2 /= NC.A_ENE FB43 W LAD NW 2 /AN NC.A_INC FC26 W <td< td=""></td<></td></t<>	Symbol Block Type Language Details gp par.IN45 FC3 R STL NV 1 FB17 R STL NV 1 FC9 R STL NV 1 FC2 W STL NV 1 FC2 R STL NV 1 FC2 R STL NV 1 FC2 M STL NV 1 FC1 M STL NV 1 FC1 M STL NV 1 NC.A_ENE FB43 M LAD NV 2 NC.A_ENE FB43 M LAD NV 2 NC.A_ENE FB43 M LAD NV 2 NC.A_INC FC26 M STL NV 1 NC.A_INC FC25 M STL NV 1 NC.A_INC FC25	Symbol Block Type Language Details gp par.INMS FC3 R STL NW 1 Sta gp par.INMS FC3 R STL NW 1 Sta FC9 R STL NW 1 Sta FC9 R STL NW 1 Sta FC2 W STL NW 1 Sta FC2 R STL NW 1 Sta FC2 W STL NW 1 Sta FC1 W STL NW 1 Sta FC1 W STL NW 1 Sta NC.A_ENE FB43 M LAD NW 1 /= NC.A_ENE FB43 W LAD NW 2 /= NC.A_ENE FB43 W LAD NW 2 /= NC.A_INC FC26 W	Symbol Block Type Language Details gp par.INMS FC3 R STL NW 1 Sta 1 FC9 R STL NW 1 Sta 1 FC9 R STL NW 1 Sta 1 FC2 W STL NW 1 Sta 1 FC2 R STL NW 1 Sta 84 FC2 R STL NW 1 Sta 82 FC2 V STL NW 1 Sta 130 FC1 W STL NW 1 Sta 122 NC.A_ENE FB43 M LAD NW 1 /= NC.A_ENE FB43 W LAD NW 2 /= NC.A_ENE FB43 W LAD NW 2 /AN NC.A_INC FC26 W <td< td=""></td<>

Fig. 20-3 (d) Cross Reference Screen

④ If there are no items you want to know in the cross reference, execute the cross reference filtering (extraction of items to be displayed) with following steps.
 Return to the ladder display screen, press Alt key, open the Options menu with
 O key, move the cursor to the Reference Data → Filter with the cursor ↑ ↓ → key and press INPUT key.

Customige	Cirl+Alt+E	1		
Display language Translating teyts	,			
Rewining Run-time properties		1		
Compare <u>B</u> locks		1		
Beference Data	•	Display	Ctrl+Alt+R	
Define <u>G</u> lobal Data		Eiker		
Configure <u>N</u> etwork.		Generate	,	
<u>S</u> imulate Modules				
Set PG/PC Interface		1		

Fig. 20-3 (e) Display Item Extraction Select Screen

⑤ Move to the item you want to know with Tab key and ↑ ↓ key, press INPUT key and check.

Closs-References As	signment Program Str	ucture Unused Symbols	
Pinputs	Filter area	Access Type	_
F Dukputa		C Sejection:	■ 3 W ■ 2 BW
ER Memory			E 2.7
Counters			□ <u>\$</u> B
₽ Imers		C Dnly multiple with operation	assignments n ''="
IF D <u>B</u> ₂		Columns	
/ I ≇B≈		🔽 5: Address	
		🖻 <u>6</u> : Symbol	
☐ <u>S</u> FBs, SFCs		Z: Block	
Eeripheral input	2	🛛 🖉 <u>B</u> : Type of Ar	ocess
Peripheral outp	uto	🛛 🖗 🖞 Block Lan	guage and Details
With "OK," the B	ter is saved as default.		

Fig. 20-3 (f) Item Select Screen

6 When the cross reference is finished, press Alt key, open the File menu with
 F key, select Exit with the cursor ↑ ↓ key and press INPUT key to close the window.

	Open Glore	CH+O
6	<u>Print</u> Print Previe <u>w</u> Page Setup Pjint Setup	Chi+P
	1 k7test/yasnac k7\\\$7 Program(1) 2 k7test/yasnac k7\\\$7 Program(1)	
	Egit	Alt+F4

Fig. 20-3 (g) EXIT Select Screen

20-4 Return to pcFLexi screen

- ① Press MENU SELECT .
- 2 Press F8/LSEIKI .
- ③ Press > .
- ④ Returns to the overall screen.

SEICOS-pcFLexi INSTRUCTION MANUAL OPERATION Version 1.01 08-2001

08-2001 First Edition